

SECTION **IDX**  
ALPHABETICAL INDEX

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

# ALPHABETICAL INDEX

## Numerics

4WD - Wiring diagram .....	<a href="#">TF-21</a>
4WD control unit inspection table .....	<a href="#">TF-28</a>

## A

A/C air flow .....	<a href="#">ATC-32</a> , <a href="#">MTC-5</a>
A/C component layout .....	<a href="#">ATC-23</a>
A/C compressor clutch removal and installation .....	<a href="#">ATC-146</a>
A/C compressor precaution .....	<a href="#">ATC-10</a>
A/C compressor special service tool .....	<a href="#">ATC-14</a>
A/C diagnostic work flow (auto A/C) .....	<a href="#">ATC-34</a>
A/C HFC134a (R134a) system precaution .....	<a href="#">ATC-4</a>
A/C HFC134a (R134a) system service procedure .....	<a href="#">ATC-141</a>
A/C HFC134a (R134a) system service tools ...	<a href="#">ATC-15</a>
A/C HFC134a system service equipment precaution ...	<a href="#">ATC-10</a>
A/C lubricant (R134a) .....	<a href="#">ATC-24</a>
A/C operational check .....	<a href="#">ATC-65</a> , <a href="#">MTC-7</a>
A/C performance test diagnoses .....	<a href="#">ATC-98</a>
A/C rera .....	<a href="#">ATC-94</a>
A/C self-diagnoses (auto A/C) .....	<a href="#">ATC-57</a>
A/C system description (auto A/C) .....	<a href="#">ATC-27</a>
A/C trouble diagnoses (auto A/C) .....	<a href="#">ATC-34</a> , <a href="#">MTC-3</a>
A/C, A - Wiring diagram .....	<a href="#">ATC-39</a>
A/T fluid checking .....	<a href="#">AT-16</a> , <a href="#">MA-38</a>
A/T fluid replacement .....	<a href="#">AT-17</a> , <a href="#">MA-39</a>
A/T fluid temperature sensor .....	<a href="#">AT-111</a>
A/T IND - Wiring diagram .....	<a href="#">DI-51</a>
A/T indicator .....	<a href="#">DI-51</a>
A/T shift lock system .....	<a href="#">AT-398</a>
A/T shift lock system - Wiring diagram .....	<a href="#">AT-399</a>
A/T trouble diagnoses .....	<a href="#">AT-57</a> , <a href="#">AT-251</a>
A/T Wiring diagram AT - 1ST .....	<a href="#">AT-127</a>
A/T Wiring diagram AT - 2ND .....	<a href="#">AT-132</a>
A/T Wiring diagram AT - 3RD .....	<a href="#">AT-137</a>
A/T Wiring diagram AT - 4TH .....	<a href="#">AT-143</a>
A/T Wiring diagram AT - BA/FTS .....	<a href="#">AT-376</a>
A/T Wiring diagram AT - CAN .....	<a href="#">AT-98</a> , <a href="#">AT-330</a>
A/T Wiring diagram AT - ENG SS .....	<a href="#">AT-121</a> , <a href="#">AT-383</a>
A/T Wiring diagram AT - FTS .....	<a href="#">AT-108</a>
A/T Wiring diagram AT - LPSV .....	<a href="#">AT-156</a> , <a href="#">AT-389</a>
A/T Wiring diagram AT - MAIN .....	<a href="#">AT-395</a>
A/T Wiring diagram AT - OVRCSV ....	<a href="#">AT-180</a> , <a href="#">AT-364</a>
A/T Wiring diagram AT - PNP/SW .....	<a href="#">AT-102</a>
A/T Wiring diagram AT - SSV/A .....	<a href="#">AT-163</a> , <a href="#">AT-352</a>
A/T Wiring diagram AT - SSV/B .....	<a href="#">AT-169</a> , <a href="#">AT-358</a>
A/T Wiring diagram AT - TCV .....	<a href="#">AT-150</a> , <a href="#">AT-370</a>
A/T Wiring diagram AT - TPS .....	<a href="#">AT-175</a> , <a href="#">AT-347</a>
A/T Wiring diagram AT - VSS A/T ....	<a href="#">AT-114</a> , <a href="#">AT-334</a>
A/T Wiring diagram AT - VSSMTR ....	<a href="#">AT-194</a> , <a href="#">AT-341</a>
Accelerator control system .....	<a href="#">ACC-2</a>
Accelerator pedal position (APP) sensor .....	<a href="#">EC-386</a> , <a href="#">EC-393</a> , <a href="#">EC-409</a> , <a href="#">EC-740</a> , <a href="#">EC-747</a> , <a href="#">EC-763</a> , <a href="#">EC-987</a> , <a href="#">EC-1025</a> , <a href="#">EC-1098</a> , <a href="#">EC-1104</a> , <a href="#">EC-1149</a> , <a href="#">EC-1297</a> , <a href="#">EC-1332</a> , <a href="#">EC-1387</a> , <a href="#">EC-1393</a> , <a href="#">EC-1437</a>

Accelerator pedal released position learning ....	<a href="#">EC-45</a> , <a href="#">EC-507</a>
Aiming adjustment .....	<a href="#">LT-4</a>
Air bag .....	<a href="#">SRS-3</a>
Air bag disposal .....	<a href="#">SRS-42</a>
Air bleeding (hydraulic clutch) .....	<a href="#">CL-7</a>
Air bleeding for brake system .....	<a href="#">BR-9</a>
Air cleaner and air duct(QR20DE•QR25DE) ....	<a href="#">EM-15</a>
Air cleaner and air duct(YD22DDTi) .....	<a href="#">EM-133</a>
Air cleaner filter replacement(QR20DE•QR25DE) .....	<a href="#">MA-23</a>
Air cleaner filter replacement(YD22DDTi) .....	<a href="#">MA-32</a>
Air cleaner filter(QR20DE•QR25DE) .....	<a href="#">EM-15</a>
Air cleaner filter(YD22DDTi) .....	<a href="#">EM-133</a>
Air conditioner cut control ....	<a href="#">EC-37</a> , <a href="#">EC-499</a> , <a href="#">EC-887</a> , <a href="#">EC-1218</a>
Air flow meter - See Mass air flow sensor .....	<a href="#">EC-149</a> , <a href="#">EC-590</a>
Air mix door control linkage adjustment .....	<a href="#">ATC-78</a> , <a href="#">ATC-135</a> , <a href="#">MTC-10</a> , <a href="#">MTC-32</a>
Air mix. door motor .....	<a href="#">ATC-76</a> , <a href="#">ATC-135</a>
Air spoiler, rear .....	<a href="#">EI-30</a>
Alternator .....	<a href="#">SC-12</a>
Ambient sensor .....	<a href="#">ATC-109</a> , <a href="#">ATC-111</a> , <a href="#">ATC-121</a>
Angular tightening application(QR20DE•QR25DE) .....	<a href="#">EM-5</a>
Angular tightening application(YD22DDTi) ....	<a href="#">EM-122</a>
Antenna - See Power antenna .....	<a href="#">AV-41</a>
APP2PW - Wiring diagram .....	<a href="#">EC-1106</a> , <a href="#">EC-1395</a>
APPS - Wiring diagram ...	<a href="#">EC-989</a> , <a href="#">EC-1299</a> , <a href="#">EC-1439</a>
APPS1 - Wiring diagram .....	<a href="#">EC-388</a> , <a href="#">EC-742</a>
APPS2 - Wiring diagram ..	<a href="#">EC-395</a> , <a href="#">EC-749</a> , <a href="#">EC-1027</a> , <a href="#">EC-1334</a>
APPS3 - Wiring diagram ...	<a href="#">EC-411</a> , <a href="#">EC-765</a> , <a href="#">EC-1151</a>
Ashtray illumination .....	<a href="#">LT-65</a>
Audio .....	<a href="#">AV-4</a>
Auto air conditioner - Wiring diagram .....	<a href="#">ATC-39</a>
Automatic amplifier .....	<a href="#">ATC-55</a> , <a href="#">ATC-67</a>
Automatic transmission fluid replacement .....	<a href="#">MA-38</a> , <a href="#">MA-39</a>
AV and NAVI control unit .....	<a href="#">AV-44</a>
Axle .....	<a href="#">MA-44</a>

## B

Back door .....	<a href="#">BL-99</a>
Back door window .....	<a href="#">GW-15</a>
Back window .....	<a href="#">GW-15</a>
BACK/L - Wiring diagram .....	<a href="#">LT-44</a>
Back-up lamp .....	<a href="#">LT-44</a> , <a href="#">LT-62</a>
Back-up lamp switch (M/T) .....	<a href="#">MT-13</a>
Barometric pressure (BARO) sensor .....	<a href="#">EC-1167</a> , <a href="#">EC-1455</a>
Basic inspection ....	<a href="#">EC-79</a> , <a href="#">EC-526</a> , <a href="#">EC-905</a> , <a href="#">EC-1231</a>
Battery .....	<a href="#">SC-3</a>
Baulk ring (M/T) .....	<a href="#">MT-20</a> , <a href="#">MT-25</a>
Blower motor ....	<a href="#">ATC-82</a> , <a href="#">ATC-87</a> , <a href="#">ATC-127</a> , <a href="#">MTC-15</a> , <a href="#">MTC-18</a> , <a href="#">MTC-24</a>
Blower resistor .....	<a href="#">MTC-25</a>

# ALPHABETICAL INDEX

Blower unit ..... [ATC-125](#), [MTC-22](#), [MTC-24](#)  
 BOOST - Wiring diagram ..... [EC-1040](#), [EC-1347](#)  
 Boring/horning cylinder block(QR20DE•QR25DE) .....  
[EM-103](#)  
 Brake booster ..... [BR-23](#)  
 Brake fluid change ..... [BR-8](#)  
 Brake fluid level ..... [MA-41](#)  
 Brake fluid level and line check ..... [BR-8](#)  
 Brake hydraulic line ..... [BR-10](#)  
 Brake inspection ..... [MA-43](#)  
 Brake lines and cables inspection ..... [MA-41](#)  
 Brake master cylinder ..... [BR-14](#)  
 Brake pedal ..... [BR-6](#)  
 Brake switch ..... [EC-380](#), [EC-733](#), [EC-1177](#), [EC-1475](#)  
 BRK/SW - Wiring diagram [EC-381](#), [EC-735](#), [EC-1178](#),  
[EC-1476](#)  
 Bulb specifications ..... [LT-92](#)  
 Bumper, front ..... [EI-14](#)  
 Bumper, rear ..... [EI-17](#)

## C

Camshaft inspection(QR20DE•QR25DE) ..... [EM-55](#)  
 Camshaft inspection(YD22DDTi) ..... [EM-171](#)  
 Camshaft position sensor (CMPS) [EC-1056](#), [EC-1062](#),  
[EC-1363](#), [EC-1369](#)  
 Camshaft position sensor (PHASE) .. [EC-254](#), [EC-646](#)  
 Camshaft(QR20DE•QR25DE) ..... [EM-53](#)  
 Camshaft(YD22DDTi) ..... [EM-170](#)  
 CAN - Wiring diagram ..... [EC-133](#), [EC-580](#), [EC-945](#),  
[EC-1269](#), [LAN-10](#), [LAN-26](#), [LAN-51](#), [LAN-69](#), [LAN-87](#)  
 CAN (Controller Area Network) ..... [BRC-8](#), [LAN-9](#),  
[LAN-25](#), [LAN-50](#), [LAN-68](#), [LAN-86](#)  
 CAN communication [EC-38](#), [EC-132](#), [EC-500](#), [EC-579](#),  
[EC-888](#), [EC-944](#), [EC-1268](#), [AT-32](#), [AT-97](#), [AT-329](#),  
[TF-43](#), [BRC-8](#), [LAN-9](#), [LAN-25](#), [LAN-50](#), [LAN-68](#),  
[LAN-86](#)  
 Canister-See EVAP canister ..... [EC-476](#), [EC-868](#)  
 CHARGE - Wiring diagram ..... [SC-13](#), [SC-14](#)  
 Charging system ..... [SC-12](#)  
 Chassis and body maintenance ..... [MA-37](#)  
 CHIME - Wiring diagram ..... [DI-52](#), [DI-55](#), [DI-56](#)  
 CIGAR - Wiring diagram ..... [WW-27](#)  
 Cigarette lighter ..... [WW-27](#)  
 Circuit breaker ..... [PG-12](#)  
 CKPS - Wiring diagram .. [EC-947](#), [EC-1046](#), [EC-1052](#),  
[EC-1271](#), [EC-1353](#), [EC-1359](#)  
 Clearance lamp ..... [LT-4](#), [LT-60](#)  
 Clock ..... [DI-61](#)  
 CLOCK - Wiring diagram ..... [DI-61](#)  
 Closed loop control ..... [EC-35](#), [EC-497](#)  
 Clutch cover ..... [CL-14](#)  
 Clutch disc ..... [CL-14](#)  
 Clutch master cylinder ..... [CL-8](#)  
 Clutch operating cylinder ..... [CL-10](#)  
 Clutch pedal ..... [CL-5](#)  
 Clutch release bearing ..... [CL-12](#)  
 Clutch release mechanism ..... [CL-12](#)  
 Clutch withdrawal lever ..... [CL-12](#)

CMPS - Wiring diagram . [EC-947](#), [EC-1058](#), [EC-1064](#),  
[EC-1271](#), [EC-1365](#), [EC-1371](#)  
 Coil spring (rear) ..... [RSU-8](#)  
 Collision diagnosis ..... [SRS-48](#)  
 Combination meter ..... [DI-4](#)  
 Combination switch ..... [LT-40](#)  
 Component Location (auto A/C) ..... [ATC-35](#), [MTC-4](#)  
 Compression pressure(QR20DE•QR25DE) .... [EM-67](#)  
 Compression pressure(YD22DDTi) ..... [EM-196](#)  
 Compressor clutch removal and installation .. [ATC-146](#)  
 Compressor special service tool ..... [ATC-14](#)  
 Condenser ..... [ATC-155](#)  
 Connecting rod bearing clearance(QR20DE•QR25DE)  
[EM-101](#)  
 Connecting rod bearing clearance(YD22DDTi) [EM-232](#)  
 Connecting rod bushing clearance(YD22DDTi) [EM-226](#)  
 Connecting rod(QR20DE•QR25DE) ..... [EM-101](#)  
 Connecting rod(YD22DDTi) ..... [EM-223](#), [EM-228](#)  
 CONSULT for engine ..... [EC-102](#), [EC-551](#)  
 CONSULT-II for engine ..... [EC-926](#), [EC-1251](#)  
 Control lever (M/T) ..... [MT-14](#)  
 Control unit ..... [ATC-120](#), [MTC-21](#)  
 Control units (terminal arrangement) ..... [PG-72](#)  
 Controller Area Network (CAN) ..... [BRC-8](#), [LAN-9](#),  
[LAN-25](#), [LAN-50](#), [LAN-68](#), [LAN-86](#)  
 Converter housing installation ..... [AT-523](#)  
 COOL/F - Wiring diagram [EC-352](#), [EC-704](#), [EC-1014](#),  
[EC-1322](#)  
 Coolant replacement(QR20DE•QR25DE) ..... [MA-20](#)  
 Coolant replacement(YD22DDTi) ..... [MA-28](#)  
 Cooling circuit (engine)(QR20DE•QR25DE) ..... [CO-7](#)  
 Cooling circuit (engine)(YD22DDTi) ..... [CO-29](#)  
 Cooling fan ..... [CO-18](#), [CO-36](#)  
 Cooling fan relay [EC-363](#), [EC-715](#), [EC-1024](#), [EC-1331](#)  
 Coupling sleeve (M/T) ..... [MT-20](#), [MT-25](#)  
 Cowl top ..... [EI-20](#)  
 Cowl top cover ..... [EI-20](#)  
 Crankcase ventilation system ..... [EC-888](#), [EC-1219](#)  
 Crankcase ventilation system - See Positive crankcase  
 ventilation ..... [EC-478](#), [EC-870](#)  
 Crankshaft position sensor (POS) .... [EC-247](#), [EC-638](#)  
 Crankshaft position sensor (TDC) [EC-1044](#), [EC-1050](#),  
[EC-1351](#), [EC-1357](#)  
 Crankshaft(QR20DE•QR25DE) ..... [EM-83](#)  
 Cylinder block boring(QR20DE•QR25DE) .... [EM-104](#)  
 Cylinder block boring(YD22DDTi) ..... [EM-230](#)  
 Cylinder block(QR20DE•QR25DE) ..... [EM-82](#)  
 Cylinder block(YD22DDTi) ..... [EM-212](#)  
 Cylinder head bolt tightening(QR20DE•QR25DE) .....  
[EM-69](#)  
 Cylinder head bolt tightening(YD22DDTi) ..... [EM-198](#)  
 Cylinder head gasket selection(YD22DDTi) .. [EM-199](#)  
 Cylinder head(QR20DE•QR25DE) ..... [EM-67](#)  
 Cylinder head(YD22DDTi) ..... [EM-196](#)

## D

Data link connector ..... [EC-469](#), [EC-861](#)  
 Data link connector for Consult ..... [EC-104](#), [EC-553](#),

## ALPHABETICAL INDEX

### [EC-926](#), [EC-1251](#)

Daytime light system ..... [LT-20](#)  
Daytime running light - See Daytime light system [LT-20](#)  
DEF - Wiring diagram ..... [GW-21](#)  
Desiccant Assembly ..... [ATC-156](#)  
Diagnosis sensor unit ..... [SRS-41](#)  
Diagnostic trouble code (DTC) ..... [EC-1223](#)  
Diagnostic trouble code (DTC) for OBD system [EC-19](#),  
[EC-54](#), [EC-482](#), [EC-513](#), [EC-874](#), [EC-894](#), [EC-1205](#)  
Diagnostic trouble code (DTC) inspection priority chart  
[EC-76](#), [EC-523](#), [EC-904](#), [EC-1230](#)  
Differential gear (FF M/T) ..... [MT-23](#), [MT-28](#)  
DLC - Wiring diagram ..... [EC-469](#), [EC-861](#)  
Door glass ..... [GW-80](#), [GW-83](#)  
Door glass Fitting Adjustment ..... [GW-80](#), [GW-83](#)  
Door lock ..... [BL-91](#), [BL-95](#)  
Door mirror ..... [GW-86](#)  
Door trim ..... [EI-32](#)  
Door, front ..... [BL-18](#)  
Door, rear ..... [BL-18](#)  
Drive belt inspection(QR20DE•QR25DE) ..... [MA-20](#)  
Drive belt inspection(YD22DDTi) ..... [MA-27](#)  
Drive belt(QR20DE•QR25DE) ..... [EM-13](#)  
Drive belt(YD22DDTi) ..... [EM-131](#)  
Drive shaft (front) ..... [FAX-11](#)  
Drive shaft (rear) ..... [RAX-10](#)  
Driver air bag ..... [SRS-30](#)  
Dropping resistor (A/T) ..... [AT-160](#), [AT-393](#)  
DTC work support ..... [EC-111](#)  
DTRL - Wiring diagram ..... [LT-20](#)  
Dual pressure switch ..... [ATC-18](#), [ATC-95](#), [ATC-158](#)  
Duct and grilles ..... [ATC-137](#), [MTC-33](#)

### E

ECM input/output signal ..... [EC-95](#), [EC-543](#)  
ECM power supply [EC-124](#), [EC-282](#), [EC-571](#), [EC-664](#),  
[EC-937](#), [EC-1261](#)  
ECM relay ..... [EC-1110](#), [EC-1399](#)  
ECM/PW - Wiring diagram ..... [EC-283](#), [EC-665](#)  
ECTS - Wiring diagram ..... [EC-164](#), [EC-599](#), [EC-983](#),  
[EC-1293](#)  
EGR function ..... [EC-1073](#), [EC-1080](#), [EC-1465](#)  
EGR volume control valve ..... [EC-1073](#), [EC-1080](#),  
[EC-1465](#)  
EGRC/V - Wiring diagram ..... [EC-1076](#), [EC-1083](#),  
[EC-1467](#)  
Electric sunroof ..... [RF-10](#)  
Electric throttle control actuator ..... [EC-290](#), [EC-292](#),  
[EC-310](#), [EC-668](#), [EC-671](#), [EC-690](#)  
Electrical load signal circuit ..... [EC-456](#), [EC-848](#)  
Electrical unit ..... [PG-72](#)  
Electrical units location ..... [PG-65](#)  
Electronic ignition (EI) system ..... [EC-37](#), [EC-499](#)  
Engine control circuit diagram [EC-93](#), [EC-541](#), [EC-917](#),  
[EC-1243](#)  
Engine control component parts location ..... [EC-88](#),  
[EC-536](#)  
Engine control module (ECM) ..... [EC-279](#), [EC-661](#),  
[EC-1089](#), [EC-1091](#), [EC-1378](#), [EC-1380](#)

Engine control system diagram and chart ..... [EC-30](#),  
[EC-492](#), [EC-883](#), [EC-1214](#)  
Engine coolant temperature sensor (ECTS) ... [EC-162](#),  
[EC-597](#), [EC-981](#), [EC-1291](#)  
Engine coolant(QR20DE•QR25DE) ..... [CO-9](#)  
Engine coolant(YD22DDTi) ..... [CO-31](#)  
Engine fail-safe system ..... [EC-77](#), [EC-524](#)  
Engine oil filter replacement(QR20DE•QR25DE) .....  
[MA-25](#)  
Engine oil filter replacement(YD22DDTi) [MA-33](#), [MA-35](#)  
Engine oil precautions ..... [GI-7](#)  
Engine oil replacement(QR20DE•QR25DE) ..... [MA-23](#)  
Engine oil replacement(YD22DDTi) ..... [MA-33](#)  
Engine oil(QR20DE•QR25DE) ..... [LU-7](#)  
Engine oil(YD22DDTi) ..... [LU-20](#)  
Engine removal(QR20DE•QR25DE) ..... [EM-78](#)  
Engine removal(YD22DDTi) ..... [EM-208](#)  
ETC1 - Wiring diagram ..... [EC-293](#), [EC-673](#)  
ETC2 - Wiring diagram ..... [EC-304](#), [EC-684](#)  
ETC3 - Wiring diagram ..... [EC-311](#), [EC-691](#)  
EVAP canister purge volume control solenoid valve ....  
[EC-265](#), [EC-473](#), [EC-809](#), [EC-865](#)  
EVAP vapor lines inspection(QR20DE•QR25DE) .....  
[MA-26](#)  
Evaporative emission (EVAP) system [EC-473](#), [EC-865](#)  
Evaporator ..... [ATC-158](#)  
Exhaust manifold(QR20DE•QR25DE) ..... [EM-23](#)  
Exhaust manifold(YD22DDTi) ..... [EM-141](#)  
Exhaust system ..... [EX-2](#)  
Exhaust system inspection ..... [EX-2](#), [MA-37](#)  
Expansion valve ..... [ATC-159](#)  
Exterior [EI-21](#), [EI-22](#), [EI-24](#), [EI-25](#), [EI-26](#), [EI-27](#), [EI-28](#),  
[EI-30](#), [EI-31](#)

### F

F/FOG - Wiring diagram ..... [LT-52](#), [LT-53](#)  
F/PUMP - Wiring diagram [EC-444](#), [EC-836](#), [EC-1134](#),  
[EC-1422](#)  
Fan control amp. .... [ATC-84](#), [ATC-129](#)  
Fan switch ..... [MTC-18](#)  
FIAR - Wiring diagram ..... [EC-1117](#), [EC-1406](#)  
Final drive (FF M/T) ..... [MT-23](#), [MT-28](#)  
Finisher, interior - See Trim ..... [EI-32](#)  
Finisher, rear panel ..... [EI-31](#)  
Floor trim ..... [EI-38](#)  
Flow charts ..... [GI-23](#)  
Fluid temperature sensor (A/T) ..... [AT-111](#)  
Fluorescent leak detector ..... [ATC-160](#)  
Flywheel (clutch) ..... [CL-14](#)  
Flywheel runout(QR20DE•QR25DE) [EM-108](#), [EM-235](#)  
Fog lamp, front ..... [LT-52](#)  
Fork rod (M/T) ..... [MT-22](#), [MT-27](#)  
Freeze frame data [EC-55](#), [EC-514](#), [EC-895](#), [EC-1223](#)  
FRO2 - Wiring diagram ..... [EC-772](#), [EC-787](#)  
Front bumper ..... [EI-14](#)  
Front disc brake ..... [BR-27](#)  
Front door ..... [BL-18](#)

# ALPHABETICAL INDEX

Front Door Trim .....	<a href="#">EI-32</a>
Front fog lamp .....	<a href="#">LT-52</a>
Front passenger air bag .....	<a href="#">SRS-35</a>
Front seat .....	<a href="#">SE-24</a>
Front seat belt .....	<a href="#">SB-3</a>
Front seat belt pre-tensioner ....	<a href="#">SB-2</a> , <a href="#">SRS-3</a> , <a href="#">SRS-40</a>
Front side air bag .....	<a href="#">SRS-37</a>
Front suspension .....	<a href="#">FSU-5</a>
Front washer .....	<a href="#">WW-4</a>
Front wiper .....	<a href="#">WW-4</a>
FRPS - Wiring diagram .....	<a href="#">EC-999</a> , <a href="#">EC-1309</a>
FTS - Wiring diagram .....	<a href="#">EC-994</a> , <a href="#">EC-1304</a>
FUEL - Wiring diagram .....	<a href="#">EC-218</a> , <a href="#">EC-225</a>
Fuel check valve .....	<a href="#">EC-473</a> , <a href="#">EC-865</a>
Fuel cut control (at no load high engine speed) .....	<a href="#">EC-38</a> , <a href="#">EC-500</a> , <a href="#">EC-887</a> , <a href="#">EC-1218</a>
Fuel filler lid .....	<a href="#">BL-103</a>
Fuel filter .....	<a href="#">EC-890</a> , <a href="#">EC-1221</a>
Fuel filter replacement(QR20DE•QR25DE) .....	<a href="#">FL-4</a>
Fuel filter replacement(YD22DDTi) .....	<a href="#">FL-17</a> , <a href="#">MA-31</a>
Fuel gauge .....	<a href="#">DI-4</a>
Fuel injection control system .....	<a href="#">EC-885</a> , <a href="#">EC-1216</a>
Fuel injection system .....	<a href="#">EC-216</a> , <a href="#">EC-223</a>
Fuel injector adjustment resistor ....	<a href="#">EC-1115</a> , <a href="#">EC-1404</a>
Fuel injector and fuel tube(QR20DE•QR25DE) ..	<a href="#">EM-32</a>
Fuel injector and fuel tube(YD22DDTi) .....	<a href="#">EM-157</a>
Fuel line inspection(QR20DE•QR25DE) ..	<a href="#">FL-3</a> , <a href="#">MA-23</a>
Fuel line inspection(YD22DDTi) .....	<a href="#">FL-16</a> , <a href="#">MA-31</a>
Fuel pressure check .....	<a href="#">EC-48</a> , <a href="#">EC-510</a>
Fuel pressure release .....	<a href="#">EC-48</a> , <a href="#">EC-510</a>
Fuel pump .....	<a href="#">EC-443</a> , <a href="#">EC-835</a> , <a href="#">EC-890</a> , <a href="#">EC-1127</a> , <a href="#">EC-1416</a>
Fuel pump and gauge(QR20DE•QR25DE) .....	<a href="#">FL-4</a>
Fuel rail pressure sensor .....	<a href="#">EC-997</a> , <a href="#">EC-1307</a>
Fuel system(QR20DE•QR25DE) .....	<a href="#">FL-3</a>
Fuel system(YD22DDTi) .....	<a href="#">FL-16</a>
Fuel tank(QR20DE•QR25DE) .....	<a href="#">FL-11</a>
Fuel tank(YD22DDTi) .....	<a href="#">FL-23</a>
Fuel temperature sensor .....	<a href="#">EC-993</a> , <a href="#">EC-1303</a>
Fuse .....	<a href="#">PG-12</a>
Fuse and fusible link box .....	<a href="#">PG-76</a>
Fusible link .....	<a href="#">PG-12</a>

## G

Gauges .....	<a href="#">DI-4</a>
Gear components (M/T) .....	<a href="#">MT-20</a> , <a href="#">MT-25</a>
Generator .....	<a href="#">SC-12</a>
Generator - See Alternator .....	<a href="#">SC-12</a>
Generic scan tool (GST) .....	<a href="#">EC-112</a> , <a href="#">EC-931</a>
Glass .....	<a href="#">GW-80</a> , <a href="#">GW-83</a>
GLOW - Wiring diagram .....	<a href="#">EC-1070</a> , <a href="#">EC-1170</a> , <a href="#">EC-1458</a>
Glow plug .....	<a href="#">EC-1169</a> , <a href="#">EC-1457</a>
Glow plug(YD22DDTi) .....	<a href="#">EM-152</a>
Glow relay .....	<a href="#">EC-1069</a> , <a href="#">EC-1169</a> , <a href="#">EC-1457</a>
GPS antenna .....	<a href="#">AV-43</a>
Grille - See Exterior .....	<a href="#">EI-19</a>
Ground distribution .....	<a href="#">PG-13</a>

## H

H/AIM - Wiring diagram .....	<a href="#">LT-29</a>
H/LAMP - Wiring diagram .....	<a href="#">LT-4</a> , <a href="#">LT-7</a>
H/MIRROR - Wiring diagram .....	<a href="#">GW-21</a>
Harness connector .....	<a href="#">PG-70</a>
Harness layout .....	<a href="#">PG-30</a>
Headlamp .....	<a href="#">LT-4</a>
Headlamp aiming control .....	<a href="#">LT-29</a>
Headlamp leveler - See Headlamp aiming control .....	<a href="#">LT-29</a>
Headlamp washer .....	<a href="#">WW-20</a>
Headlining - See Roof trim .....	<a href="#">EI-39</a>
Heated oxygen sensor 1 ....	<a href="#">EC-176</a> , <a href="#">EC-183</a> , <a href="#">EC-193</a> , <a href="#">EC-318</a> , <a href="#">EC-324</a> , <a href="#">EC-611</a> , <a href="#">EC-618</a> , <a href="#">EC-786</a>
Heated oxygen sensor 1 heater .....	<a href="#">EC-138</a> , <a href="#">EC-771</a>
Heated oxygen sensor 2 ....	<a href="#">EC-201</a> , <a href="#">EC-208</a> , <a href="#">EC-330</a> , <a href="#">EC-338</a> , <a href="#">EC-792</a>
Heated oxygen sensor 2 heater .....	<a href="#">EC-144</a> , <a href="#">EC-776</a>
Heated seat .....	<a href="#">SE-18</a> , <a href="#">SE-21</a>
HEATER - Wiring diagram .....	<a href="#">MTC-6</a>
Heater and cooling unit (Heater core) .....	<a href="#">ATC-131</a>
Heater mirror .....	<a href="#">GW-21</a>
Heater system - Wiring diagram .....	<a href="#">MTC-6</a>
Heater unit (heater core) ..	<a href="#">ATC-136</a> , <a href="#">MTC-27</a> , <a href="#">MTC-30</a>
HFC134a (R134a) system precaution .....	<a href="#">ATC-4</a>
HFC134a (R134a) system service procedure .....	<a href="#">ATC-141</a>
HFC134a (R134a) system service tools .....	<a href="#">ATC-15</a>
HFC134a system service equipment precaution .....	<a href="#">ATC-10</a>
HO2S1 - Wiring diagram .....	<a href="#">EC-178</a> , <a href="#">EC-186</a> , <a href="#">EC-196</a> , <a href="#">EC-613</a> , <a href="#">EC-620</a>
HO2S1H - Wiring diagram .....	<a href="#">EC-140</a>
HO2S2 - Wiring diagram ....	<a href="#">EC-203</a> , <a href="#">EC-211</a> , <a href="#">EC-333</a> , <a href="#">EC-341</a>
HO2S2H - Wiring diagram .....	<a href="#">EC-146</a>
Hood .....	<a href="#">BL-12</a>
Horn .....	<a href="#">WW-25</a>
HORN - Wiring diagram .....	<a href="#">WW-25</a>
How to erase DTC .....	<a href="#">EC-514</a> , <a href="#">EC-1223</a>
How to erase DTC for OBD system ....	<a href="#">EC-63</a> , <a href="#">EC-895</a>

## I

IATS - Wiring diagram .....	<a href="#">EC-158</a> , <a href="#">EC-977</a> , <a href="#">EC-1287</a>
IATSEN - Wiring diagram .....	<a href="#">EC-782</a>
Identification .....	<a href="#">ATC-12</a> , <a href="#">ATC-13</a>
Idle air volume learning .....	<a href="#">EC-46</a> , <a href="#">EC-508</a>
Idle speed .....	<a href="#">EC-79</a> , <a href="#">EC-526</a> , <a href="#">EC-905</a> , <a href="#">EC-1231</a>
Ignition coil .....	<a href="#">EC-417</a> , <a href="#">EC-798</a>
Ignition coil(QR20DE•QR25DE) .....	<a href="#">EM-29</a>
Ignition control system .....	<a href="#">EC-417</a> , <a href="#">EC-798</a>
Ignition timing .....	<a href="#">EC-79</a> , <a href="#">EC-526</a>
IGNSYS - Wiring diagram .....	<a href="#">EC-418</a> , <a href="#">EC-799</a>
ILL - Wiring diagram .....	<a href="#">LT-66</a>
Illumination .....	<a href="#">LT-66</a>
In vehicle sensor .....	<a href="#">ATC-111</a> , <a href="#">ATC-113</a> , <a href="#">ATC-122</a>
INJE/PW - Wiring diagram .....	<a href="#">EC-1158</a> , <a href="#">EC-1446</a>
INJECT - Wiring diagram ..	<a href="#">EC-429</a> , <a href="#">EC-821</a> , <a href="#">EC-1008</a>



# ALPHABETICAL INDEX

[EC-1124](#), [EC-1163](#), [EC-1317](#), [EC-1413](#), [EC-1451](#)  
Injection nozzle(YD22DDTi) ..... [EM-157](#)  
Injector ..... [EC-428](#), [EC-820](#)  
Input shaft (FF M/T) ..... [MT-20](#), [MT-25](#)  
Intake air temperature sensor ..... [EC-156](#), [EC-781](#),  
[EC-976](#), [EC-1286](#)  
Intake door control linkage adjustment ..... [ATC-81](#)  
Intake door motor [ATC-79](#), [ATC-128](#), [MTC-11](#), [MTC-26](#)  
Intake manifold(QR20DE•QR25DE) ..... [EM-17](#)  
Intake manifold(YD22DDTi) ..... [EM-136](#)  
Intake sensor ..... [ATC-117](#)  
Intake valve timing control ..... [EC-135](#), [EC-582](#)  
Intake valve timing control solenoid valve ..... [EC-286](#)  
Interior ..... [EI-32](#), [EI-34](#), [EI-35](#), [EI-38](#), [EI-39](#)  
Interior lamp ..... [LT-76](#)  
Interior lamp on-off control ..... [LT-76](#), [LT-77](#)  
ISO 15031-5 Mode 1 - 9 ..... [EC-51](#), [EC-892](#)  
IVC - Wiring diagram ..... [EC-287](#)

## J

Joint connector (J/C) ..... [PG-75](#)

## K

Keyless entry system - See Multi-remote control system  
[BL-74](#)

Knock sensor (KS) ..... [EC-242](#), [EC-633](#)  
KS - Wiring diagram ..... [EC-243](#), [EC-634](#)

## L

LAN system circuit ..... [ATC-69](#)  
License lamp ..... [LT-47](#)  
Line pressure test (A/T) ..... [AT-68](#), [AT-260](#)  
Liquid gasket application ..... [LU-3](#), [LU-17](#)  
Liquid gasket application(QR20DE•QR25DE) ... [EM-6](#),  
[EM-123](#), [CO-3](#), [CO-25](#)  
LOAD - Wiring diagram ..... [EC-457](#), [EC-849](#)  
Location of electrical units ..... [PG-65](#)  
Lock, door ..... [BL-91](#), [BL-95](#)  
Lubricant (R134a) A/C ..... [ATC-5](#), [ATC-24](#)  
Lubrication circuit (engine)(QR20DE•QR25DE) .. [LU-5](#)  
Lubrication circuit (engine)(YD22DDTi) ..... [LU-19](#)  
Lubrication oil A/C ..... [ATC-164](#)  
Lubrication-locks, hinges and hood latches ..... [MA-45](#)

## M

M/T major overhaul ..... [MT-28](#), [MT-37](#)  
M/T oil replacement ..... [MT-11](#)  
M/T removal and installation ..... [MT-17](#)  
MAFS - Wiring diagram ..... [EC-151](#), [EC-592](#), [EC-965](#),  
[EC-972](#), [EC-1282](#)  
Magnet clutch ..... [ATC-88](#), [ATC-146](#)  
MAIN - Wiring diagram ..... [EC-124](#), [EC-571](#), [EC-938](#),  
[EC-1262](#)  
Mainshaft (M/T) ..... [MT-20](#), [MT-25](#)  
Maintenance (engine)(YD22DDTi) ..... [MA-27](#)

Major overhaul (Transfer) ..... [TF-57](#)  
Malfunction indicator (MI) .... [EC-64](#), [EC-516](#), [EC-896](#),  
[EC-1224](#)  
Mass air flow sensor (MAFS) ..... [EC-149](#), [EC-590](#),  
[EC-963](#), [EC-970](#), [EC-1280](#)  
Master cylinder (brake) ..... [BR-14](#)  
Master cylinder (clutch) ..... [CL-8](#)  
Meter ..... [DI-4](#)  
METER - Wiring diagram ..... [DI-14](#), [DI-17](#)  
MIL/DL - Wiring diagram ..... [EC-1202](#), [EC-1498](#)  
MIRROR - Wiring diagram ..... [GW-87](#)  
Mirror defogger ..... [GW-21](#)  
Mirror, door ..... [GW-86](#)  
Mirror, out side ..... [GW-86](#)  
Misfire ..... [EC-237](#)  
Mode door control linkage adjustment ..... [ATC-75](#),  
[ATC-134](#), [MTC-9](#), [MTC-31](#)  
Mode door motor ..... [ATC-73](#), [ATC-134](#)  
Molding - See Exterior ..... [EI-22](#), [EI-24](#), [EI-25](#)  
Mud guard - See Exterior ..... [EI-24](#)  
MULTI - Wiring diagram ..... [BL-77](#)  
Multiport fuel injection (MFI) system ... [EC-34](#), [EC-496](#)  
Multiport fuel injection precautions ..... [GI-6](#)  
Multi-remote control system ..... [BL-74](#)

## N

NATS - Wiring diagram ..... [BL-111](#)  
NATS (Nissan anti-theft system) ..... [BL-108](#)  
NATS (Nissan anti-theft system) precautions ..... [GI-3](#)  
NVH troubleshooting (BR) ..... [BR-5](#)  
NVH troubleshooting (Transfer) ..... [TF-8](#)

## O

Oil cooler (engine)(QR20DE•QR25DE) ..... [LU-11](#)  
Oil cooler (engine)(YD22DDTi) ..... [LU-28](#)  
Oil filter(QR20DE•QR25DE) ..... [LU-10](#)  
Oil filter(YD22DDTi) ..... [LU-23](#)  
Oil pan (engine)(QR20DE•QR25DE) ..... [EM-25](#)  
Oil pan (engine)(YD22DDTi) ..... [EM-147](#)  
Oil pressure (engine)(QR20DE•QR25DE) ..... [LU-7](#)  
Oil pressure (engine)(YD22DDTi) ..... [LU-20](#)  
Oil pump (engine)(QR20DE•QR25DE) ..... [LU-13](#)  
Oil pump (engine)(YD22DDTi) ..... [LU-30](#)  
Oil seal replacement (engine)(QR20DE•QR25DE) .....  
[EM-44](#), [EM-67](#), [EM-82](#)  
On board diagnostic system . [EC-51](#), [EC-513](#), [EC-892](#)  
Operating cylinder (clutch) ..... [CL-10](#)  
Out side mirror ..... [GW-86](#)  
Overdrive control switch ..... [AT-240](#), [AT-327](#)  
Overheat ..... [EC-348](#), [EC-700](#), [EC-1011](#), [EC-1320](#)  
Oversize piston(QR20DE•QR25DE) ..... [EM-104](#)  
Oversize piston(YD22DDTi) ..... [EM-230](#)

## P

Park/Neutral position switch [EC-373](#), [EC-725](#), [EC-816](#),  
[EC-1182](#), [EC-1479](#)

# ALPHABETICAL INDEX

Park/neutral position switch (A/T) ..... [AT-100](#)  
 Park/neutral position switch (M/T) ..... [MT-13](#)  
 PCV (positive crankcase ventilation) . [EC-478](#), [EC-870](#)  
 PGC/V - Wiring diagram ..... [EC-267](#)  
 PHASE - Wiring diagram ..... [EC-255](#), [EC-648](#)  
 Pilot bushing replacement - See Pilot  
 converter(QR20DE•QR25DE) ..... [EM-82](#)  
 Piston assembly(QR20DE•QR25DE) ..... [EM-103](#)  
 Piston pin inspection(QR20DE•QR25DE) ..... [EM-99](#)  
 Piston pin inspection(YD22DDTi) ..... [EM-222](#)  
 Piston ring inspection(QR20DE•QR25DE) ..... [EM-100](#)  
 Piston ring inspection(YD22DDTi) ..... [EM-227](#)  
 Piston to bore clearance(QR20DE•QR25DE) . [EM-103](#)  
 Piston to bore clearance(YD22DDTi) ..... [EM-230](#)  
 PNP/SW - Wiring diagram [EC-375](#), [EC-727](#), [EC-1183](#),  
[EC-1480](#)  
 PNPSW1 - Wiring diagram ..... [EC-817](#)  
 POS - Wiring diagram ..... [EC-248](#), [EC-640](#)  
 POWER - Wiring diagram ..... [PG-3](#)  
 Power antenna ..... [AV-41](#)  
 Power door lock ..... [BL-22](#)  
 Power seat ..... [SE-10](#)  
 Power socket ..... [WW-29](#)  
 Power steering fluid level ..... [PS-6](#), [MA-44](#)  
 Power steering gear ..... [PS-13](#)  
 Power steering oil pressure switch [EC-1186](#), [EC-1483](#)  
 Power steering oil pump ..... [PS-24](#)  
 Power steering pressure (PSP) sensor ..... [EC-274](#),  
[EC-656](#)  
 Power supply routing ..... [PG-2](#)  
 Power window ..... [GW-40](#)  
 Precautions for Leak detection dye ..... [ATC-12](#)  
 Precautions (General) ..... [GI-4](#)  
 Pre-delivery inspection ..... [MA-4](#)  
 Pressure plate - See Clutch cover ..... [CL-14](#)  
 PRGVLV - Wirng diagram ..... [EC-810](#)  
 Propeller shaft ..... [PR-3](#)  
 Propeller shaft on vehicle service ..... [PR-3](#)  
 PS/SEN - Wiring diagram ..... [EC-275](#), [EC-657](#)  
 PST/SW - Wiring diagram ..... [EC-1187](#), [EC-1484](#)

## Q

Quick-glow system ..... [EC-1169](#), [EC-1457](#)

## R

R/FOG - Wiring diagram ..... [LT-56](#)  
 Radiator(QR20DE•QR25DE) ..... [CO-12](#), [CO-14](#)  
 Radiator(YD22DDTi) ..... [CO-34](#), [CO-38](#)  
 Radio - See Audio ..... [AV-4](#)  
 Rear air spoiler ..... [EI-30](#)  
 Rear bumper ..... [EI-17](#)  
 Rear disc brake ..... [BR-32](#)  
 Rear door ..... [BL-18](#)  
 Rear fog lamp ..... [LT-56](#)  
 Rear panel finisher ..... [EI-31](#)  
 Rear seat ..... [SE-31](#)  
 Rear seat belt ..... [SB-4](#)

Rear side window ..... [GW-13](#)  
 Rear suspension ..... [RSU-5](#)  
 Rear washer ..... [WW-14](#)  
 Rear window defogger ..... [GW-17](#)  
 Rear wiper ..... [WW-14](#)  
 Refrigerant connection precaution ..... [ATC-5](#)  
 Refrigerant discharging evacuating charging [ATC-141](#)  
 Refrigerant general precaution ..... [ATC-5](#)  
 Refrigerant lines ..... [ATC-141](#)  
 Refrigerant pressure sensor [EC-451](#), [EC-843](#), [ATC-18](#),  
[ATC-94](#), [ATC-157](#)  
 Refrigeration cycle ..... [ATC-18](#)  
 Release bearing (clutch) ..... [CL-12](#)  
 Removal and installation (A/T) ..... [AT-413](#)  
 Removal and installation (Transfer) ..... [TF-55](#)  
 Reverse idler shaft (M/T) ..... [MT-20](#), [MT-25](#)  
 Reverse lamp switch (M/T) - See Back-up lamp switch  
 (M/T) ..... [MT-13](#)  
 Reverse main gear (M/T) ..... [MT-20](#), [MT-25](#)  
 Rocker cover(QR20DE•QR25DE) ..... [EM-42](#)  
 Rocker cover(YD22DDTi) ..... [EM-168](#)  
 Room lamp ..... [LT-76](#)  
 Room lamp - See Interior lamp ..... [LT-76](#)  
 ROOM/L - Wiring diagram ..... [LT-76](#)  
 RP/SEN - Wiring diagram ..... [EC-452](#), [EC-844](#)  
 RRO2 - Wiring diagram ..... [EC-777](#), [EC-793](#)

## S

S/LOCK - Wiring diagram ..... [BL-24](#), [BL-45](#)  
 S/SIG - Wiring diagram ..... [EC-1199](#), [EC-1496](#)  
 SCTC/V - Wiring diagram ..... [EC-1095](#), [EC-1129](#),  
[EC-1136](#), [EC-1141](#), [EC-1146](#), [EC-1384](#), [EC-1418](#),  
[EC-1424](#), [EC-1429](#), [EC-1434](#)  
 SEAT - Wiring diagram ..... [SE-11](#)  
 Seat belt inspection ..... [MA-45](#)  
 Seat belt pre-tensioner disposal ..... [SRS-42](#)  
 Seat belt, front ..... [SB-3](#)  
 Seat belt, rear ..... [SB-4](#)  
 Seat, front ..... [SE-24](#)  
 Seat, rear ..... [SE-31](#)  
 Self-diagnosis (Transfer) ..... [TF-30](#)  
 SEN/PW - Wiring diagram ..... [EC-369](#), [EC-721](#)  
 Sheft warning system ..... [BL-104](#)  
 SHIFT - Wiring diagram ..... [AT-399](#)  
 Shift control components (M/T) ..... [MT-22](#), [MT-27](#)  
 Shift fork (M/T) ..... [MT-22](#), [MT-27](#)  
 Shift lever ..... [MT-14](#)  
 Shift lock system ..... [AT-398](#)  
 Shift schedule ..... [AT-530](#)  
 Shift solenoid valve A (A/T) ..... [AT-128](#)  
 Shift solenoid valve B (A/T) ..... [AT-128](#)  
 Side air bag (satellite) sensor ..... [SRS-39](#)  
 Side window - See Rear side window ..... [GW-13](#)  
 Spark plug replacement(QR20DE•QR25DE) ... [MA-26](#)  
 Spark plug(QR20DE•QR25DE) ..... [EM-30](#)  
 Specification value ..... [EC-119](#), [EC-566](#)  
 Speedometer ..... [DI-4](#)  
 Spiral cable ..... [SRS-33](#)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

IDX

## ALPHABETICAL INDEX

SROOF - Wiring diagram ..... [RF-11](#)  
 SRS - See Supplemental Restraint System ..... [SRS-6](#)  
 SRS - Wiring diagram/LHD ..... [SRS-11](#)  
 SRS - Wiring diagram/RHD ..... [SRS-13](#)  
 SRS Trouble diagnoses ..... [SRS-8](#)  
 Stall test (A/T) ..... [AT-65](#), [AT-257](#)  
 Standardized relay ..... [PG-73](#)  
 START - Wiring diagram ..... [SC-22](#), [SC-23](#)  
 Start signal ..... [EC-1199](#), [EC-1496](#)  
 Starter ..... [SC-21](#)  
 Starting system ..... [SC-21](#)  
 Steering gear and linkage inspection ..... [MA-43](#)  
 Steering knuckle ..... [FAX-7](#)  
 Steering linkage ..... [PS-13](#)  
 Steering wheel and column ..... [PS-7](#), [PS-10](#)  
 Stop lamp ..... [LT-42](#), [LT-62](#)  
 Stop lamp switch ..... [EC-380](#), [EC-733](#)  
 STOP/L - Wiring diagram ..... [LT-42](#), [LT-62](#)  
 Suction control valve .... [EC-1093](#), [EC-1139](#), [EC-1144](#),  
[EC-1382](#), [EC-1427](#), [EC-1432](#)  
 Sunload sensor ..... [ATC-114](#), [ATC-116](#), [ATC-123](#)  
 Sunroof ..... [RF-10](#)  
 Super lock ..... [BL-42](#)  
 Supplemental Restraint System ..... [SRS-6](#)  
 Supplemental restraint system - Wiring diagram/LHD ..  
[SRS-11](#)  
 Supplemental restraint system - Wiring diagram/RHD .  
[SRS-13](#)  
 Suspension ..... [MA-44](#)  
 Symbols and abbreviations ..... [GI-9](#), [GI-22](#)  
 Symptom matrix chart ..... [EC-84](#), [EC-532](#)  
 Synchronizer (M/T) ..... [MT-20](#), [MT-25](#)  
 System readiness test (SRT) code ..... [EC-55](#)

### T

Tachometer ..... [DI-4](#)  
 Tail lamp ..... [LT-47](#), [LT-60](#)  
 TAIL/L - Wiring diagram ..... [LT-47](#), [LT-88](#)  
 Tailgate lamp ..... [LT-47](#)  
 TC boost control solenoid valve ..... [EC-949](#), [EC-1345](#),  
[EC-1471](#)  
 TC boost sensor ..... [EC-1038](#)  
 TCC/V - Wiring diagram ..... [EC-951](#), [EC-1472](#)  
 TCM circuit diagram ..... [AT-21](#)  
 TCM inspection table ..... [AT-94](#), [AT-286](#)  
 THEFT - Wiring diagram ..... [BL-104](#)  
 Thermal protector ..... [ATC-95](#)  
 Thermostat(QR20DE•QR25DE) ..... [CO-22](#)  
 Thermostat(YD22DDTi) ..... [CO-45](#)  
 Three way catalyst function ..... [EC-261](#)  
 Three way catalyst precautions ..... [GI-5](#)  
 Three way catalyst(QR20DE•QR25DE) ..... [EM-23](#)  
 Throttle control motor relay ..... [EC-302](#), [EC-682](#)  
 Throttle position sensor (TPS) ..... [EC-168](#), [EC-229](#),  
[EC-364](#), [EC-366](#), [EC-401](#), [EC-603](#), [EC-625](#), [EC-716](#),  
[EC-718](#), [EC-755](#)  
 Throwout bearing - See Clutch release bearing [CL-12](#)  
 Time control system ..... [BCS-3](#)

Timing chain(QR20DE•QR25DE) ..... [EM-44](#)  
 Timing chain(YD22DDTi) ..... [EM-180](#), [EM-185](#)  
 Torque converter installation ..... [AT-415](#), [AT-523](#)  
 TPS1 - Wiring diagram ..... [EC-231](#), [EC-627](#)  
 TPS2 - Wiring diagram ..... [EC-170](#), [EC-605](#)  
 TPS3 - Wiring diagram ..... [EC-403](#), [EC-757](#)  
 Transmission case (M/T) ..... [MT-19](#), [MT-24](#)  
 Trouble diagnoses ..... [GI-10](#)  
 Turbocharger charge air cooler(YD22DDTi) .. [EM-135](#)  
 Turbocharger precautions ..... [GI-6](#)  
 Turbocharger(YD22DDTi) ..... [EM-141](#)  
 TURN - Wiring diagram ..... [LT-31](#), [LT-33](#)  
 Turn signal lamp ..... [LT-31](#), [LT-62](#)  
 Two trip detection logic ..... [EC-51](#), [EC-513](#)

### V

Vacuum hose (brake system) ..... [BR-25](#)  
 Vacuum hose drawing (Engine control) [EC-32](#), [EC-494](#)  
 Vacuum pump(YD22DDTi) ..... [EM-153](#)  
 Valve clearance(QR20DE•QR25DE) ..... [EM-61](#)  
 Valve clearance(YD22DDTi) ..... [EM-175](#)  
 Valve guide ..... [EM-73](#)  
 Valve guide(QR20DE•QR25DE) ..... [EM-74](#)  
 Valve lifter(QR20DE•QR25DE) ..... [EM-53](#)  
 Valve lifter(YD22DDTi) ..... [EM-173](#)  
 Valve seat(QR20DE•QR25DE) ..... [EM-75](#)  
 Valve seat(YD22DDTi) ..... [EM-205](#)  
 Valve spring(QR20DE•QR25DE) ..... [EM-77](#)  
 Variable induction air control system (VIAS) ... [EC-434](#),  
[EC-826](#)  
 Vehicle speed sensor (VSS) [EC-272](#), [EC-378](#), [EC-654](#),  
[EC-730](#)  
 Ventilation air filter ..... [ATC-130](#)  
 VIAS - Wiring diagram ..... [EC-436](#), [EC-828](#)

### W

WARN - Wiring diagram ..... [DI-34](#), [DI-42](#)  
 Warning chime ..... [DI-54](#)  
 Warning lamps ..... [DI-33](#)  
 Washer, front ..... [WW-4](#)  
 Washer, rear ..... [WW-14](#)  
 Water control valve(QR20DE•QR25DE) ..... [CO-22](#)  
 Water pump(QR20DE•QR25DE) ..... [CO-20](#)  
 Water pump(YD22DDTi) ..... [CO-42](#)  
 Water temperature gauge ..... [DI-4](#)  
 Weatherstrip - See Exterior ..... [BL-21](#)  
 Wheel alignment (front) ..... [FSU-6](#)  
 Wheel alignment (rear) ..... [RSU-6](#)  
 Wheel balance ..... [WT-4](#), [MA-41](#)  
 Wheel bearing (rear) ..... [RAX-6](#)  
 Wheel hub (front) ..... [FAX-7](#)  
 Wheel hub (rear) ..... [RAX-6](#)  
 Wheel sensors (ABS) ..... [BRC-45](#)  
 WINDOW - Wiring diagram ..... [GW-46](#)  
 Window, back ..... [GW-15](#)  
 Window, back door ..... [GW-15](#)  
 Window, door ..... [GW-80](#), [GW-83](#)



## ALPHABETICAL INDEX

Window, rear side .....	<a href="#">GW-13</a>
Window, side - See Rear side window .....	<a href="#">GW-13</a>
WIP/R - Wiring diagram .....	<a href="#">WW-14</a>
WIPER - Wiring diagram .....	<a href="#">WW-6</a>
Wiper and washer .....	<a href="#">WW-4</a>
Wiper, front .....	<a href="#">WW-4</a>
Wiper, rear .....	<a href="#">WW-14</a>
Wiring Diagram (Cell code) list .....	<a href="#">PG-61</a>
Wiring diagrams .....	<a href="#">GI-14</a>
Withdrawal lever (clutch) .....	<a href="#">CL-12</a>
Wrist pin - See Piston pin inspection(QR20DE•QR25DE) .....	<a href="#">EM-99</a>

A

B

C

D

E

F

G

H

I

J

K

L

IDX