

A

EX

EX

C

D

E

F

G

H

I

J

K

L

M

SECTION EX
EXHAUST SYSTEM

CONTENTS

EXHAUST SYSTEM	2	SERVICE DATA AND SPECIFICATIONS (SDS)	5	F
Checking Exhaust System	2	Tightening Torque	5	
Removal and Installation	2	QR20DE AND QR25DE	5	
QR20DE AND QR25DE	2	YD22DDTI	5	G
YD22DDTI	3			
REMOVAL	3			
INSTALLATION	3			H
INSPECTION AFTER INSTALLATION	4			

EXHAUST SYSTEM

EXHAUST SYSTEM


PFP:20100

Checking Exhaust System

EBS00AZ6

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.




Removal and Installation

EBS003DN

CAUTION:

- Be sure to use genuine exhaust system parts or equivalents which are specially designed for heat resistance, corrosion resistance and shape.
- Perform the operation with the exhaust system fully cooled down because the system will be hot just after engine stops.
- Be careful not to cut your hand on the insulator edge.

QR20DE AND QR25DE



- | | | |
|-------------------------|----------------------------|-----------------------|
| 1. Main muffler | 2. Mounting rubber | 3. Spring |
| 4. Gasket | 5. Three way catalyst | 6. Exhaust front tube |
| 7. Seal bearing | 8. Mounting rubber bracket | 9. Mounting bracket |
| 10. Exhaust center tube | | |

A
EX
C
D
E
F
G
H
I
J
K
L
M

EX



- J
K
L
M

K
L
M

L
M

L

M

L

M

M

- M


EXHAUST SYSTEM

Exhaust Front Tube Side (QR20DE and QR25DE)

Insert seal bearing in the direction shown in the figure.

CAUTION:

Tighten mounting bolt without causing interference with exhaust front tube flange.




Main Muffler Side (QR20DE, QR25DE and YD22DDTi)

Insert seal bearing in the direction shown in the figure.

CAUTION:

Tighten mounting bolt without causing interference with main muffler flange.



INSPECTION AFTER INSTALLATION

- With the engine running, check exhaust tube joints for gas leakage and unusual noises.
- Check to ensure that mounting brackets and mounting rubbers are installed properly and free from undue stress. Improper installation could result in excessive noise and vibration.

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Tightening Torque QR20DE AND QR25DE

EBS00KP4

Unit: N·m (kg-m, ft-lb)

Exhaust system connections		
Exhaust manifold three way catalyst assembly to exhaust front tube		43.1 - 54.9 (4.4 - 5.5, 32 - 40)
Exhaust front tube to three way catalyst		51.0 - 64.7 (5.2 - 6.5, 38 - 47)
Three way catalyst to exhaust center tube		51.0 - 64.7 (5.2 - 6.5, 38 - 47)
Exhaust center tube to main muffler		43.1 - 54.9 (4.4 - 5.5, 32 - 40)
Mounting bolts and nuts	M8	12.7 - 15.7 (1.3 - 1.6, 10 - 11)

YD22DDTI

Unit: N·m (kg-m, ft-lb)

Exhaust system connections		
Catalyst rear diffuser to exhaust front tube		59.8 - 69.6 (6.1 - 7.0, 45 - 51)
Exhaust front tube to exhaust tube		51.0 - 64.7 (5.2 - 6.5, 38 - 47)
Exhaust tube to exhaust center tube		51.0 - 64.7 (5.2 - 6.5, 38 - 47)
Exhaust center tube to main muffler		43.1 - 54.9 (4.4 - 5.5, 32 - 40)
Mounting bolts and nuts	M8	12.7 - 15.7 (1.3 - 1.6, 10 - 11)

SERVICE DATA AND SPECIFICATIONS (SDS)
