

SECTION

RAX

REAR AXLE

A

B

C

RAX

CONTENTS

E

PRECAUTIONS	2	REAR DRIVE SHAFT	10	F
Caution	2	Removal and Installation	10	
PREPARATION	3	REMOVAL	10	
Special Service Tools (SST)	3	INSPECTION AFTER REMOVAL	10	G
NOISE, VIBRATION AND HARSHNESS (NVH)		INSTALLATION	10	
TROUBLESHOOTING	5	Disassembly and Assembly	11	
NVH Troubleshooting Chart	5	DISASSEMBLY	11	H
WHEEL HUB (4WD)	6	INSPECTION AFTER DISASSEMBLY	12	
On-Vehicle Inspection	6	ASSEMBLY	12	
REAR WHEEL BEARING	6	SERVICE DATA AND SPECIFICATIONS (SDS)	15	I
Removal and Installation	6	Wheel Bearing	15	
REMOVAL	7	Drive Shaft	15	
INSTALLATION	7			J
Disassembly and Assembly	7			K
DISASSEMBLY	7			L
INSPECTION AFTER DISASSEMBLY	8			M
ASSEMBLY	8			

PRECAUTIONS

PRECAUTIONS

PFP:00001

Caution

EDS00060

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

- After installing removed suspension parts, check wheel alignment and adjust if necessary.

Observe the following precautions when disassembling and servicing drive shaft.

- Perform work in a location which is as dust-free and dirt-free as possible.
- Before disassembling and servicing, clean the outside of parts.
- The disassembly and service location must be clean. Care must be taken to prevent parts from becoming dirty and to prevent the entry of foreign objects.
- Disassembled parts must be carefully reassembled in the correct order. If work is interrupted, a clean cover must be placed over parts.
- Paper shop cloths must be used. Fabric shop cloths must not be used because of the danger of lint adhering to parts.
- Disassembled parts (except for rubber parts) should be cleaned with kerosene which shall be removed by blowing with air or wiping with paper shop cloths.

PREPARATION

PREPARATION

PFP:00002

Special Service Tools (SST)

EDS00061

A

B

C

RAX

E

F

G

H








I

J




K

L

M

Tool number Tool name		Description
KV40104100 Attachment	 ZZA0804D	Removing wheel hub and bearing assembly
ST36230000 Sliding hammer	 ZZA0803D	Removing wheel hub and bearing assembly
ST33061000 Drift a: 28.5 mm (1.122 in) dia. b: 38.0 mm (1.496 in) dia.	 ZZA0969D	Removing inner race on outer side of wheel bearings
ST15242000 Drift b: 69 mm (2.72 in) dia.	 ZZA0881D	Removing wheel bearing
KV40105310 Drift a: 75 mm (2.95 in) dia. b: 62 mm (2.44 in) dia.	 ZZA1003D	<ul style="list-style-type: none"> Removing wheel bearing Installing wheel hubs
ST30720000 Drift a: 77.0 mm (3.031 in) dia. b: 55.5 mm (2.185 in) dia.	 ZZA0811D	Removing wheel bearing
Drift ST33200000 a: 60.0 mm (2.362 in) dia. b: 44.5 mm (1.752 in) dia.	 ZZA1002D	Installing wheel hub

PREPARATION

Tool number Tool name		Description
KV38107800 Protector a: 29 mm (1.41 in) dia.	 <p>ZZA0835D</p>	Installing drive shaft
Drift KV38100500 a: 80 mm (3.15 in) dia. b: 60 mm (2.36 in) dia.	 <p>ZZA0701D</p>	Installing sensor rotor
KV40101840 Collar a: 67 mm (2.64 in) dia. b: 85 mm (3.35 in) dia.	 <p>ZZA1113D</p>	Installing sensor rotor

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

EDS000FK

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page			—	RAX-12	—	RAX-6, RAX-10	—	NVH in PR section.	NVH in RFD section.	NVH in FAX and FSU sections.	Refer to REAR AXLE in this chart.	NVH in WT section.	NVH in WT section.	Refer to DRIVE SHAFT in this chart.	NVH in BR section.	NVH in PS section.
Possible cause and SUSPECTED PARTS			Excessive joint angle	Joint sliding resistance	Imbalance	Improper installation, looseness	Parts interference	PROPELLER SHAFT	DIFFERENTIAL	FRONT AXLE AND FRONT SUSPENSION	REAR AXLE	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	DRIVE SHAFT	Noise	x	x				x	x	x	x	x	x		x	x
		Shake	x		x			x		x	x	x	x		x	x
	REAR AXLE	Noise				x	x	x	x	x		x	x	x	x	x
		Shake				x	x	x		x		x	x	x	x	x
		Vibration				x	x	x		x		x		x		x
		Shimmy				x	x			x		x	x		x	x
		Judder				x				x		x	x		x	x
		Poor quality ride or handling				x	x			x		x	x			

x: Applicable

A
B
C
RAX
E
F
G
H
I
J
K
L
M

WHEEL HUB (4WD)

WHEEL HUB (4WD)


PFP:43202

On-Vehicle Inspection

EDS00065

Inspect to check that there is no excessive play, cracking, wear, or other damage to rear axle.

- Turn rear wheels (left/right) and check the play.



REAR WHEEL BEARING

With vehicle raised, inspect the following.


- Move wheel hub in the axial direction by hand. Check that there is no looseness of rear wheel bearing.

Axial end play : 0.05 mm (0.002 in) or less

- Rotate wheel hub and check that there is no unusual noise or other irregular condition. If there are any irregular condition, replace wheel bearing.

Removal and Installation

EDS00066



- | | | |
|------------------|---------------|-----------------|
| 1. Cotter pin | 2. Lock nut | 3. Wheel hub |
| 4. Hub bolt | 5. Back plate | 6. Axle housing |
| 7. Wheel bearing | 8. Snap ring | |

WHEEL HUB (4WD)

REMOVAL

1. Remove tyre.
2. Remove wheel hub lock nut.

CAUTION:


Discard the old hub lock nut; replace with new one.

3. Remove brake caliper from axle housing and hang it up somewhere.

CAUTION:

Avoid depressing the brake pedal while the brake caliper is removed.

4. Remove disc rotor and parking brake assembly from back plate and axle housing.
5. Remove wheel sensor from axle housing.
6. Remove axle housing from strut.
7. Remove nut and bolt from axle housing side of radius rod.
8. Remove nuts and bolts from axle housing side of front and rear parallel link. Remove axle housing from vehicle.



INSTALLATION

- Refer to component parts drawing for tightening torque. For installation, follow removal procedure in reverse order.


Disassembly and Assembly

DISASSEMBLY


1. Set axle housing on bench vise. As shown in the figure, use attachment (SST) and sliding hammer (SST) to remove wheel hub and bearing assembly from axle housing.

CAUTION:

When placing onto bench vise, be careful not to damage strut mounting surface of steering knuckle. Use an aluminum plate or another suitable tool.




2. Use a bearing replacer (suitable tool), puller (suitable tool), and drift (SST) to remove inner race of outer-wheel bearing from wheel hub.
3. Remove back plate installation bolt and anchor block. Remove back plate from axle housing. Refer to [PB-4, "Components"](#)
4. Use a flat-bladed screwdriver or similar tool to remove snap ring.



WHEEL HUB (4WD)

5. Use a drift (SST) to remove wheel bearing from axle housing.



INSPECTION AFTER DISASSEMBLY

Wheel Hub

- Inspect wheel hub for deformation, cracks, and other damage. If any irregular conditions are found, replace wheel hub.

Axle Housing

- Inspect axle housing for deformation, cracks, and other damage. If any irregular conditions are found, replace axle housing.

Snap Ring

- Check snap ring for deformation, cracks, and other damage. If any irregular conditions are found, replace snap ring.


ASSEMBLY

1. Use a drift (SST) to press fit wheel bearing into axle housing.


CAUTION:

Discard the old wheel bearing; replace with a new one.

2. Use a flat-bladed screwdriver or similar tool to install the snap ring.
3. Install back plate and anchor block onto axle housing. Refer to [PB-4, "Components"](#).



4. Use a drift (SST) to install wheel hub onto axle housing.
5. After completing step 4, apply an additional load of 49,030 N (5,000 kg, 11,025 lb). Rotate axle housing in forward and reverse directions 10 times each to ensure a good fit.



6. Place a spring balance at the point where the strut is joined (upper side bolt hole) and measure rotating torque when spring is pulled at a speed of 8 -12 rpm. Refer to the [RAX-15, "Wheel Bearing"](#) item.

Rotating torque : 1.96 N-m (0.20 kg-m, 17 in-lb) or less

Spring balance reading : 12.8 N (1.30 kg, 2.87 lb) or less

NOTE:

If a load of 49,030 N (5,000 kg, 11,025 lb) cannot be applied:

- Install to drive shaft and tighten wheel hub lock nut to specified torque. Rotate in forward and reverse direction 10 times each to ensure a good fit.
- At a rotating speed of 8 - 12 rpm, place a spring balance on hub bolt and measure rotating torque.

WHEEL HUB (4WD)

Rotating torque : 1.126 N·m (0.11 kg-m, 10 in-lb)
Spring balance reading : 19.70 N (2.01 kg, 4.43 lb)

- A
- B
- C
- RAX
- E
- F
- G
- H
- I
- J
- K
- L
- M

REAR DRIVE SHAFT


REAR DRIVE SHAFT

PFP:39600

Removal and Installation

EDS000FL

SEC.396




REMOVAL

1. Remove axle housing. Refer to [RAX-7, "REMOVAL"](#).

NOTE:

In order to remove the rear drive shaft assembly, the rear axle is removed. At this time it is recommended that front and rear parallel links on axle side be loosened (not removed). This will facilitate wheel alignment inspection and adjustment which are carried out later.

2. As shown in the figure, use a wheel wrench or similar tool to remove drive shaft from rear final drive.



INSPECTION AFTER REMOVAL

- Move the joint in the up/down, left/right, and axial directions. Check for any rough movement or significant looseness.
- Check boot for cracks or other damage, and also for grease leakage.


INSTALLATION

1. In order to prevent damage to rear final drive side oil seal, first fit a protector (SST) onto oil seal before inserting drive shaft. Slide drive shaft into slide joint and tap with a hammer to install securely.

CAUTION:

Be sure to check that circular clip is securely fastened.

2. Install rear axle. Refer to [RAX-7, "INSTALLATION"](#).



REAR DRIVE SHAFT

Disassembly and Assembly

EDS000FM

A

B

C

RAX

E

F

G

H


I

J

K

L

M




- | | | |
|-----------------|---------------------------|--------------------|
| 1. Sensor rotor | 2. Joint sub assembly | 3. Circular clip |
| 4. Boot bands | 5. Boot | 6. Shaft |
| 7. Boot | 8. Boot bands | 9. Spider assembly |
| 10. Snap ring | 11. Housing (Slide joint) | 12. Circular clip |

DISASSEMBLY


Final Drive Side

1. Remove boot bands.
 2. Fix shaft to bench vise.
- CAUTION:**
When fixing shaft to bench vise, be sure to protect it with a copper or aluminum sheet.
3. Make alignment marks on shaft and spider assembly.
- CAUTION:**
Use paint or similar substance for alignment marks. Do not scratch the surface.
4. Remove snap ring. Remove spider assembly from shaft.
 5. Remove boot from shaft.
 6. Remove old grease on slide joint assembly with paper towels.
 7. Remove circular clip and dust shield from slide joint assembly.



Wheel Side

1. As shown in the figure, use a bearing replacer (suitable tool) and puller (suitable tool) to remove sensor rotor from drive shaft.
 2. Fix shaft to bench vise.
- CAUTION:**
When fixing shaft to bench vise, be sure to protect it with a copper or aluminum sheet.
3. Remove boot bands. Remove boot from joint sub-assembly.




REAR DRIVE SHAFT

4. Screw a drive shaft puller (suitable tool) 30 mm (1.18 in) or more into threaded part of joint sub-assembly. Pull joint sub-assembly out of shaft.

CAUTION:

If joint sub assembly cannot be removed after five or more unsuccessful attempts, replace the entire drive shaft assembly.

5. Remove boot from shaft.
6. Remove circular clip from shaft.
7. Remove old grease.



INSPECTION AFTER DISASSEMBLY

Shaft

- Replace shaft if there is any runout, cracking, or other damage.

Joint Sub-Assembly

- Check that there is no rough rotation or unusual axial looseness.
- Check that there is no foreign material inside joint.

CAUTION:

If there are any irregular conditions of joint assembly components, replace the entire joint assembly.

Slide Joint Side

Housing and spider assembly

- If roller or roller surface of spider assembly has scratch or wear, replace housing and spider assembly.

NOTE:

Housing and spider assembly are components which are used as a set.

ASSEMBLY


Final Drive Side

1. Wind serrated part of drive shaft with tape. Install boot band and boot to shaft. Be careful not to damage boot.

CAUTION:

Discard the old boot band and boot; replace with new ones.

2. Remove protective tape wound around serrated part of shaft.




3. Line up alignment marks which were made when spider assembly was removed. Install spider assembly, with serration chamfer facing drive shaft.

4. Secure spider assembly with snap ring.

CAUTION:

Discard the old snap ring; replace with a new one.

5. Apply grease (Nissan genuine grease or equivalent) to spider assembly and sliding surface.
6. Install housing to spider assembly. Add remaining grease (Nissan genuine grease or equivalent) up to the amount listed below.




Grease amount : 40 - 50 g (1.41 - 1.77 oz)

REAR DRIVE SHAFT

7. Install boot securely into grooves (indicated by * marks) shown in the figure.

CAUTION:

If there is grease on boot mounting surfaces (indicated by * marks) of joint, boot may come off. Remove all grease from surfaces.




8. Check that boot installation length "L" is the length indicated below. Insert a flat-bladed screwdriver or similar tool into smaller side of boot. Remove air from boot to prevent boot deformation.

Boot installation length:

78.6 - 80.6 mm (3.094 - 3.173 in)

CAUTION:


- Boot may break if boot installation length is less than standard value.
- Be careful that screwdriver tip does not contact inside surface of boot.



9. Secure big and small ends of boot with new boot bands as shown in figure.

CAUTION:

Rotate housing and check that boot installation position does not change. If position changes, reinstall boot bands.




Wheel Side

1. Use a drift (SST) to press-fit sensor rotor into joint sub-assembly.

CAUTION:

Discard the old sensor rotor; replace with a new one.




REAR DRIVE SHAFT

2. Wind serrated part of drive shaft with tape. Install boot band and boot to shaft. Be careful not to damage boot.

CAUTION:

Discard the old boot band and boot; replace with new ones.

3. Remove protective tape wound around serrated part of shaft.




4. Attach circular clip to shaft. At this time, circular clip must fit securely into the shaft groove. Attach nut to joint sub-assembly. Use a wooden hammer to press-fit.

CAUTION:

Discard the old circular clip; replace with a new one.

5. Insert the amount of grease (Nissan genuine grease or equivalent) listed below into housing from large end of boot.

Grease amount : 35 - 45 g (1.23 - 1.59 oz)



6. Install boot securely into grooves (indicated by * marks) shown in the figure.


CAUTION:

If there is grease on boot mounting surfaces (indicated by * marks) of joint sub-assembly, boot may come off. Remove all grease from surfaces.

7. Check that boot installation length "L" is the length indicated below. Insert a flat-bladed screwdriver or similar tool into smaller side of boot. Remove air from boot to prevent boot deformation.

Boot installation length:

66.7 - 68.7 mm (2.626 - 2.705 in)




CAUTION:

- Boot may break if boot installation length is less than standard value.
- Be careful that screwdriver tip does not contact inside surface of boot.

8. Secure big and small ends of boot with new boot bands as shown in the figure.

CAUTION:

Rotate housing and check that boot installation position does not change. If position changes, reinstall boot bands.



SERVICE DATA AND SPECIFICATIONS (SDS)


SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Wheel Bearing

EDS0001D

Rotation torque	1.96 N·m (0.20 kg-m, 17 in-lb) or less
Spring balance reading	12.8 N (1.30 kg) or less
Installation location of spring balance	mm (in)
Axial end play	0.05 mm (0.0020 in) or less




Drive Shaft


EDS0001E

Specified amount of grease	Final drive side	40 - 50 g (1.41 - 1.77 oz)
	Wheel side	35 - 45 g (1.23 - 1.59 oz)
Boot length	Final drive side (L2)	78.6 - 80.6 mm (3.094 - 3.173 in)
	Wheel side (L1)	66.7 - 68.7 mm (2.626 - 2.705 in)

Final drive side



Wheel drive side



SDIA0618E

SERVICE DATA AND SPECIFICATIONS (SDS)
