

# SECTION LAN

## LAN SYSTEM

### CONTENTS

<b>CAN</b>		
<b>PRECAUTIONS</b> .....	<b>3</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	
Precautions For Trouble Diagnosis .....	3	
CAN SYSTEM .....	3	
Precautions For Harness Repair .....	3	
CAN SYSTEM .....	3	
<b>CAN COMMUNICATION</b> .....	<b>4</b>	
System Description .....	4	
CAN Communication Unit .....	4	
TYPE 1 .....	4	
TYPE 2 .....	5	
TYPE 3/TYPE4 .....	6	
TYPE 5 .....	7	
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>9</b>	
System Description .....	9	
Component Parts and Harness Connector Location .....	9	
Wiring Diagram — CAN — .....	10	
Work Flow .....	12	
CHECK SHEET .....	13	
CHECK SHEET RESULTS (EXAMPLE) .....	14	
Between ABS Actuator and Electric Unit (Control Unit) and 4WD Control Unit Circuit Inspection .....	19	
ECM Circuit Inspection .....	20	
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection .....	21	
4WD Control Unit Circuit Inspection .....	21	
Combination Meter Circuit Inspection .....	22	
CAN Communication Circuit Inspection .....	22	
Component Inspection .....	24	
CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT .....	24	
<b>CAN SYSTEM (TYPE 2)</b> .....	<b>25</b>	
System Description .....	25	
Component Parts and Harness Connector Location .....	25	
Wiring Diagram — CAN — .....	26	
Work Flow .....	28	
CHECK SHEET .....	29	
CHECK SHEET RESULTS (EXAMPLE) .....	30	
Between TCM and ABS Actuator and Electric Unit (Control Unit) Circuit Inspection .....	37	
Between ABS Actuator and Electric Unit (Control Unit) and 4WD Control Unit Circuit Inspection .....	39	
ECM Circuit Inspection .....	41	
TCM Circuit Inspection .....	42	
ABS Actuator and Electric Unit (Control Unit) Circuit Inspection .....	42	
4WD Control Unit Circuit Inspection .....	43	
Combination Meter Circuit Inspection .....	43	
CAN Communication Circuit Inspection .....	44	
Component Inspection .....	49	
CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT .....	49	
<b>CAN SYSTEM (TYPE 3)</b> .....	<b>50</b>	
System Description .....	50	
Component Parts and Harness Connector Location .....	50	
Wiring Diagram — CAN — .....	51	
Work Flow .....	53	
CHECK SHEET .....	54	
CHECK SHEET RESULTS (EXAMPLE) .....	55	
Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection .....	61	
ECM Circuit Inspection .....	62	
ESP/TCS/ABS Control Unit Circuit Inspection .....	63	
Steering Angle Sensor Circuit Inspection .....	63	
4WD Control Unit Circuit Inspection .....	64	
Combination Meter Circuit Inspection .....	64	
CAN Communication Circuit Inspection .....	65	
Component Inspection .....	67	
CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT .....	67	
<b>CAN SYSTEM (TYPE 4)</b> .....	<b>68</b>	
System Description .....	68	
Component Parts and Harness Connector Location .....	68	
Wiring Diagram — CAN — .....	69	
Work Flow .....	71	
CHECK SHEET .....	72	
CHECK SHEET RESULTS (EXAMPLE) .....	73	

---

Between ESP/TCS/ABS Control Unit and 4WD	CHECK SHEET .....	90
Control Unit Circuit Inspection .....	CHECK SHEET RESULTS (EXAMPLE) .....	91
ECM Circuit Inspection .....	Between TCM and ESP/TCS/ABS Control Unit Cir-	
ESP/TCS/ABS Control Unit Circuit Inspection .....	cuit Inspection .....	99
Steering Angle Sensor Circuit Inspection .....	Between ESP/TCS/ABS Control Unit and 4WD	
4WD Control Unit Circuit Inspection .....	Control Unit Circuit Inspection .....	101
Combination Meter Circuit Inspection .....	ECM Circuit Inspection .....	103
CAN Communication Circuit Inspection .....	TCM Circuit Inspection .....	104
Component Inspection .....	ESP/TCS/ABS Control Unit Circuit Inspection .....	104
CHECK ECM AND COMBINATION METER	Steering Angle Sensor Circuit Inspection .....	105
INTERNAL CIRCUIT .....	4WD Control Unit Circuit Inspection .....	105
<b>CAN SYSTEM (TYPE 5) .....</b>	Combination Meter Circuit Inspection .....	106
System Description .....	CAN Communication Circuit Inspection .....	107
Component Parts and Harness Connector Location..	Component Inspection .....	111
Wiring Diagram — CAN — .....	CHECK ECM AND COMBINATION METER	
Work Flow .....	INTERNAL CIRCUIT .....	111

## PRECAUTIONS

PFP:00001

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS001U0

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### Precautions For Trouble Diagnosis CAN SYSTEM


EKS001U1

- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


### Precautions For Harness Repair CAN SYSTEM

EKS001U2

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



## CAN COMMUNICATION

## System Description

EKS001U3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## CAN Communication Unit


EKS00EGL

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Wagon				
Axle	4WD				
Engine	QR20DE/QR25DE		QR25DE	YD22DDTi	QR25DE
Transmission	M/T	A/T	M/T		A/T
Brake control	ABS		ESP		
CAN system type	1	2	3	4	5
CAN system trouble diagnosis	<a href="#">LAN-9</a>	<a href="#">LAN-25</a>	<a href="#">LAN-50</a>	<a href="#">LAN-68</a>	<a href="#">LAN-86</a>

## TYPE 1

## System diagram



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
Stop lamp switch signal		T	R	
Engine speed signal	T		R	R
Engine coolant temperature signal	T			R
Accelerator pedal position signal	T		R	
A/C compressor feedback signal	T			R
Vehicle speed signal		T	R	R
	R			T


# CAN COMMUNICATION

[CAN]

Signals	ECM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
ABS warning lamp signal		T		R
4WD warning lamp signal			T	R
4WD mode indicator lamp signal			T	R
Parking brake switch signal			R	T
MI signal	T			R

## TYPE 2

### System diagram



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
Stop lamp switch signal		R			T
			T	R	
P-N range signal		R			T
A/T position indicator lamp signal		T			R
Overdrive control switch signal		R			T
O/D OFF indicator signal		T			R
Closed throttle position signal	T	R			
Wide open throttle position signal	T	R			
Engine speed signal	T			R	R
Engine coolant temperature signal	T				R
Accelerator pedal position signal	T			R	
Output shaft revolution signal	R	T			
A/C compressor feedback signal	T				R
Vehicle speed signal			T	R	R
	R				T
ABS warning lamp signal			T		R


# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	4WD control unit	Combination meter
4WD warning lamp signal				T	R
4WD mode indicator lamp signal				T	R
Parking brake switch signal				R	T
MI signal	T				R
Engine A/T integrated control signal	T	R			
	R	T			
A/T self-diagnosis signal	R	T			

## TYPE 3/TYPE4

### System diagram



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ESP/TCS/ABS control unit	Steering angle sensor	4WD control unit	Combination meter
Stop lamp switch signal		T		R	
Engine speed signal	T	R		R	R
Engine coolant temperature signal	T				R
Accelerator pedal position signal	T	R		R	
A/C switch signal*1	R				T
A/C compressor feedback signal*2	T				R
Vehicle speed signal		T		R	R
	R				T
ABS warning lamp signal		T			R
Brake warning lamp signal		T			R
SLIP indicator lamp signal		T			R
ESP OFF indicator lamp signal		T			R
4WD warning lamp signal				T	R
4WD mode indicator lamp signal				T	R
Parking brake switch signal				R	T

# CAN COMMUNICATION

[CAN]


Signals	ECM	ESP/TCS/ABS control unit	Steering angle sensor	4WD control unit	Combination meter
MI signal	T				R
Glow indicator lamp signal*1	T				R
Steering angle sensor signal		R	T		

\*1: YD engine models only

\*2: QR engine models only

## TYPE 5

### System diagram



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ESP/TCS/ABS control unit	Steering angle sensor	4WD control unit	Combination meter
Stop lamp switch signal		R				T
P·N range signal		R				T
A/T position indicator lamp signal		T	R			R
O/D OFF indicator signal		T				R
Overdrive control switch signal		R				T
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Engine speed signal	T		R		R	R
Engine coolant temperature signal	T					R
Accelerator pedal position signal	T		R		R	
Output shaft revolution signal	R	T				
A/C compressor feedback signal	T					R
Vehicle speed signal			T		R	R
	R					T
ABS warning lamp signal			T			R
Brake warning lamp signal			T			R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ESP/TCS/ ABS control unit	Steering angle sensor	4WD control unit	Combination meter
SLIP indicator lamp signal			T			R
ESP OFF indicator lamp signal			T			R
4WD warning lamp signal					T	R
4WD mode indicator lamp signal					T	R
Parking brake switch signal					R	T
MI signal	T					R
Steering angle sensor signal			R	T		
Engine and A/T integrated	T	R				
	R	T				
A/T self-diagnosis signal	R	T				




**CAN SYSTEM (TYPE 1)****System Description**

EKS00F07

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

**Component Parts and Harness Connector Location**

EKS00F08



A

B

C

D

E

F

G

H

I

J

LAN

L


M

## Wiring Diagram — CAN —

EKS00F09

## LAN-CAN-01

- : DATA LINE  
 (L) : LHD MODELS  
 (R) : RHD MODELS  
 \*1 13 : (L)  
 10 : (R)  
 \*2 4 : (L)  
 3 : (R)



1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20							

(M75) : (L)  
BR




1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(M75) : (R)  
BR

REFER TO THE FOLLOWING.

(M118), (E69) -ELECTRICAL  
UNITS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




## Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	




SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
		F.F.DATA	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-13, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-13, "CHECK SHEET"](#).

**NOTE:**

- If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.
  - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.
5. According to the check sheet results (example), start inspection. Refer to [LAN-14, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

## CHECK SHEET

## NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—

Symptoms:

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

## CHECK SHEET RESULTS (EXAMPLE)

## NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.


## Case 1

Check harness between ABS actuator and electric unit (control unit) and 4WD control unit. Refer to [LAN-19](#), "Between ABS Actuator and Electric Unit (Control Unit) and 4WD Control Unit Circuit Inspection".

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—

PKIA9599E

//// : Malfunctioning part



PKIA6502E

# CAN SYSTEM (TYPE 1)

[CAN]


## Case 2

Check ECM circuit. Refer to [LAN-20, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN ✓	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN	—	—

PKIA9600E

//// : Malfunctioning part



PKIA6503E

LAN


## Case 3

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-21, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN ✓	—	—

PKIA9601E

//// : Malfunctioning part



PKIA6504E




Case 4

Check 4WD control unit circuit. Refer to [LAN-21, "4WD Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	—
ALL MODE AWD/4WD	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—

PKIA9602E

//// : Malfunctioning part



PKIA6505E

# CAN SYSTEM (TYPE 1)

[CAN]


## Case 5

Check combination meter circuit. Refer to [LAN-22, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—

PKIA9603E

//// : Malfunctioning part



PKIA6506E

**Case 6**

Check CAN communication circuit. Refer to [LAN-22, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR					
	Initial diagnosis	Transmit diagnosis	Receive diagnosis			
			ECM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKN✓WN	—	—	—	UNKN✓WN
ABS	NG	UNKN✓WN	UNKN✓WN	—	UNKN✓WN	—
ALL MODE AWD/4WD	NG	UNKN✓WN	UNKN✓WN	UNKN✓WN	—	—

PKIA9604E

## Between ABS Actuator and Electric Unit (Control Unit) and 4WD Control Unit Circuit Inspection

EKS00F0E

### 1. CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect battery cable at negative terminal.
- Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E116
  - Harness connector M75

#### OK or NG

OK >> GO TO 2.


NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and harness connector E116.
- Check the following.
  - LHD models
  - Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and harness connector E116 terminals 14 (W), 5 (R).

**20 (W) – 14 (W) : Continuity should exist.**


**23 (R) – 5 (R) : Continuity should exist.**



- RHD models
- Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and harness connector E116 terminals 9 (W), 2 (R).

**20 (W) – 9 (W) : Continuity should exist.**

**23 (R) – 2 (R) : Continuity should exist.**



#### OK or NG

OK >> GO TO 3.


NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector M75 terminals 14 (W), 5 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**14 (W) – 8 (W) : Continuity should exist.**


**5 (R) – 16 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector M75 terminals 9 (W), 2 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**9 (W) – 8 (W) : Continuity should exist.**

**2 (R) – 16 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-12, "Work Flow"](#).
- NG >> Repair harness.

## ECM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector M75
  - Harness connector E116

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and ABS actuator and electric unit (control unit).



## ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

EKS00F8C

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W) and 23 (R).

**20 (W) – 23 (R) : Approx. 54 – 66Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.



## 4WD Control Unit Circuit Inspection

EKS00FAZ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of 4WD control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check resistance between 4WD control unit harness connector M107 terminals 8 (W) and 16 (R).

**8 (W) – 16 (R) : Approx. 54 – 66Ω**

OK or NG

- OK >> Replace 4WD control unit.  
 NG >> Repair harness between 4WD control unit and combination meter.



EKS00FB0

## Combination Meter Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and 4WD control unit.



EKS00F0M

## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, connector side and harness side).

- ECM
- ABS actuator and electric unit (control unit)
- 4WD control unit
- Combination meter
- Between ECM and combination meter

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ECM connector and harness connector M75.
2. Check continuity between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Continuity should not exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness between ECM and harness connector M75.



## 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector M118 terminals 94 (G/R), 86 (GY/R) and ground.


**94 (G/R) – Ground : Continuity should not exist.**

**86 (GY/R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector M75.



## 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W) and 23 (R).

**20 (W) – 23 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.



## 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and ground.


**20 (W) – Ground : Continuity should not exist.**

**23 (R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect 4WD control unit connector and combination meter connector.
2. Check continuity between combination meter harness connector M44 terminals 22 (W) and 23 (R).


**22 (W) – 23 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and harness connector M75



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between combination meter harness connector M44 terminals 22 (W), 23 (R) and ground.

**22 (W) – Ground : Continuity should not exist.**


**23 (R) – Ground : Continuity should not exist.**

OK or NO

OK >> GO TO 8.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and harness connector M75



## 8. CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

Check components inspection. Refer to [LAN-24, "CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-12, "Work Flow"](#).


NG >> Replace ECM and/or combination meter.

### Component Inspection

#### CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 22 and 23.

Unit	Terminal	Resistance (Ω) (Approx.)
ECM	94 – 86	108 – 132
Combination meter	22 – 23	



EKS00F00

PKIA0830E



CAN SYSTEM (TYPE 2)


System Description

EKS00FHZ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00FIO




# CAN SYSTEM (TYPE 2)


[CAN]

## Wiring Diagram — CAN —

EKS00F11

### LAN-CAN-03



1	2	3	4	5	6			7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22	23	24

1	2	3	4	5			6	7	8	9
10	11	12	13	14	15	16	17	18	19	20

(M75)  
BR


1	2	3	4	5
6	7	8	9	

(F36) GY

REFER TO THE FOLLOWING.


(M118), (E69), (F46)  
-ELECTRICAL UNITS



TKWB0108E



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40

M44  
W

1	2	3	4	5			6	7	8	9
10	11	12	13	14	15	16	17	18	19	20

 :   
BR

1	2	3			4	5	6	7
8	9	10	11	12	13	14	15	16

M75 : R  
BR

8	7	6	5	4	3	2	1
16	15	14	13	12	11	10	9


M107  
W

## Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	




SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
		F.F.DATA	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-29, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-29, "CHECK SHEET"](#).

**NOTE:**

- If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.
  - The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.
5. According to the check sheet results (example), start inspection. Refer to [LAN-30, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—

Symptoms:

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

## CHECK SHEET RESULTS (EXAMPLE)

## NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.


## Case 1

Check harness between TCM and ABS actuator and electric unit (control unit). Refer to [LAN-37, "Between TCM and ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—

PKIA9606E

////// : Malfunctioning part




PKIA6495E

**Case 2**

Check harness between ABS actuator and electric unit (control unit) and 4WD control unit. Refer to [LAN-39, "Between ABS Actuator and Electric Unit \(Control Unit\) and 4WD Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—

PKIA9607E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-41, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN ✓	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—

PKIA9608E



PKIA6497E




Case 4

Check TCM circuit. Refer to LAN-42. "TCM Circuit Inspection" .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN ✓	—	—	UNKWN
A/T	NG	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—

PKIA9609E



## CAN SYSTEM (TYPE 2)


[CAN]

### Case 5

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-42, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN ✓	UNKWN ✓	—	—	UNKWN ✓	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—

PKIA9610E




Case 6

Check 4WD control unit circuit. Refer to LAN-43, "4WD Control Unit Circuit Inspection" .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—

PKIA9611E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-43, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—

PKIA9612E



PKIA6501E

**Case 8**

Check CAN communication circuit. Refer to [LAN-44, "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	TCM	VDC/TCS /ABS	AWD/4WD	METER/M&A
ENGINE	NG	UN <del>KN</del> WN	—	UN <del>KN</del> WN	—	—	UN <del>KN</del> WN
A/T	NG	UN <del>KN</del> WN	UN <del>KN</del> WN	—	—	—	UN <del>KN</del> WN
ABS	NG	UN <del>KN</del> WN	UN <del>KN</del> WN	—	—	UN <del>KN</del> WN	—
ALL MODE AWD/4WD	NG	UN <del>KN</del> WN	UN <del>KN</del> WN	—	UN <del>KN</del> WN	—	—

PKIA9613E

## Between TCM and ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

EKS00F13

### 1. CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect battery cable at negative terminal.
- Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - LHD models
    - Harness connector F41
    - Harness connector M61
    - Harness connector M75
    - Harness connector E116
  - RHD models
    - Harness connector F36
    - Harness connector E60

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

LAN


## 2. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models

1. Disconnect TCM connector and harness connector F41.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and harness connector F41 terminals 21 (G/R), 8 (GY/R).

**5 (G/R) – 21 (G/R) : Continuity should exist.**


**6 (GY/R) – 8 (GY/R) : Continuity should exist.**



3. Disconnect harness connector M75.
4. Check continuity between harness connector M61 terminals 21 (L/R), 8 (B/W) and harness connector M75 terminals 13 (L/R), 4 (B/W).

**21 (L/R) – 13 (L/R) : Continuity should exist.**

**8 (B/W) – 4 (B/W) : Continuity should exist.**




### RHD models

1. Disconnect TCM connector and harness connector F36.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and harness connector F36 terminals 4 (G/R), 5 (GY/R).

**5 (G/R) – 4 (G/R) : Continuity should exist.**

**6 (GY/R) – 5 (GY/R) : Continuity should exist.**



### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check the following.

– LHD models

- Check continuity between harness connector E116 terminals 13 (W), 4 (R) and ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R).

**13 (W) – 20 (W) : Continuity should exist.**

**4 (R) – 23 (R) : Continuity should exist.**




– RHD models

- Check continuity between harness connector E60 terminals 4 (W), 5 (R) and ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R).

**4 (W) – 20 (W) : Continuity should exist.**

**5 (R) – 23 (R) : Continuity should exist.**



OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-28, "Work Flow"](#).

NG >> Repair harness.

### Between ABS Actuator and Electric Unit (Control Unit) and 4WD Control Unit Circuit Inspection

EKS00FI4

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E116
  - Harness connector M75

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E116.
2. Check the following.

– LHD models

- Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and harness connector E116 terminals 14 (W), 5 (R).

**20 (W) – 14 (W) : Continuity should exist.**

**23 (R) – 5 (R) : Continuity should exist.**




– RHD models

- Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and harness connector E116 terminals 9 (W), 2 (R).

**20 (W) – 9 (W) : Continuity should exist.**

**23 (R) – 2 (R) : Continuity should exist.**



OK or NG

OK >> GO TO 3.

NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector M75 terminals 14 (W), 5 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**14 (W) – 8 (W) : Continuity should exist.**


**5 (R) – 16 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector M75 terminals 9 (W), 2 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**9 (W) – 8 (W) : Continuity should exist.**

**2 (R) – 16 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-28, "Work Flow"](#).
- NG >> Repair harness.

## ECM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector M61
  - Harness connector F41

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace ECM.  
NG >> Repair harness between ECM and TCM.



EKS00F16

## TCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Approx. 54 – 66Ω**

OK or NG

- OK >> Replace TCM.  
NG >> ● LHD models  
– Repair harness between TCM and harness connector F41.  
● RHD models  
– Repair harness between TCM and harness connector F36.



SKIB0094E

## ABS Actuator and Electric Unit (Control Unit) Circuit Inspection

EKS00F17

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W) and 23 (R).

**20 (W) – 23 (R)**

**: Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.



EKS00F18

## 4WD Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of 4WD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect 4WD control unit connector.
2. Check resistance between 4WD control unit harness connector M107 terminals 8 (W) and 16 (R).

**8 (W) – 16 (R)**

**: Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace 4WD control unit.  
 NG >> Repair harness between 4WD control unit and combination meter.



EKS00F19

## Combination Meter Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and 4WD control unit.



EKS00FIA

## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, connector side and harness side).
  - ECM
  - TCM
  - ABS actuator and electric unit (control unit)
  - 4WD control unit
  - Combination meter
  - Between ECM and combination meter

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector M61.
2. Check continuity between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector M61.



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector M118 terminals 94 (G/R), 86 (GY/R) and ground.


**94 (G/R) – Ground : Continuity should not exist.**

**86 (GY/R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector M61.



A

B

C

D

E

F

G

H

I

J

LAN

L


M

## 4. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models


1. Disconnect TCM connector.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Continuity should not exist.**



3. Disconnect harness connector M75.
4. Check continuity between harness connector M61 terminals 21 (L/R) and 8 (B/W).


**21 (L/R) – 8 (B/W) : Continuity should not exist.**



### RHD models

1. Disconnect TCM connector and harness connector F36.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Continuity should not exist.**



### OK or NG

OK >> GO TO 5.

NG >> ● LHD models

Check the following harness. If any harness is damaged, repair the harness.

- Harness between TCM and harness connector F41
- Harness between harness connector M61 and harness connector M75

● RHD models

- Repair harness between TCM and harness connector F36.


## 5. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models

1. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and ground.

**5 (G/R) – Ground : Continuity should not exist.**


**6 (GY/R) – Ground : Continuity should not exist.**



2. Check continuity between harness connector M61 terminals 21 (L/R), 8 (B/W) and ground.

**21 (L/R) – Ground : Continuity should not exist.**

**8 (B/W) – Ground : Continuity should not exist.**




### RHD models

- Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and ground.

**5 (G/R) – Ground : Continuity should not exist.**

**6 (GY/R) – Ground : Continuity should not exist.**



### OK or NG

OK >> GO TO 6.

NG >> • LHD models

Check the following harness. If any harness is damaged, repair the harness.


- Harness between TCM and harness connector F41
- Harness between harness connector M61 and Harness connector M75
- RHD models
- Repair harness between TCM and harness connector F36.

## 6. CHECK HARNESS FOR SHORT CIRCUIT

### LHD models

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W) and 23 (R).


**20 (W) – 23 (R) : Continuity should not exist.**



### RHD models

1. Disconnect ABS actuator and electric unit (control unit) connector and harness connector E116.
2. Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W) and 23 (R).

**20 (W) – 23 (R) : Continuity should not exist.**



### OK or NG

- OK >> GO TO 7.  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.

## 7. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ABS actuator and electric unit (control unit) harness connector E69 terminals 20 (W), 23 (R) and ground.

**20 (W) – Ground : Continuity should not exist.**

**23 (R) – Ground : Continuity should not exist.**

### OK or NG

- OK >> GO TO 8.  
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E116.






## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect 4WD control unit connector and combination meter connector.
2. Check continuity between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 9.
- NG >> Check the following harness. If any harness is damaged, repair the harness.
- Harness between combination meter and 4WD control unit
  - Harness between combination meter and harness connector M75



## 9. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between combination meter harness connector M44 terminals 22 (W), 23 (R) and ground.

**22 (W) – Ground : Continuity should not exist.**

**23 (R) – Ground : Continuity should not exist.**

OK or NO

- OK >> GO TO 10.
- NG >> Check the following harness. If any harness is damaged, repair the harness.
- Harness between combination meter and 4WD control unit
  - Harness between combination meter and harness connector M75



## 10. CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

Check components inspection. Refer to [LAN-49, "CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT"](#).

OK or NG


- OK >> Connect all the connectors and diagnose again. Refer to [LAN-28, "Work Flow"](#).
- NG >> Replace ECM and/or combination meter.

### Component Inspection

#### CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 22 and 23.

Unit	Terminal	Resistance (Ω) (Approx.)
ECM	94 – 86	108 – 132
Combination meter	22 – 23	




**CAN SYSTEM (TYPE 3)****System Description**

EKS00FV3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

**Component Parts and Harness Connector Location**

EKS00FV4




Wiring Diagram — CAN —

EKS00FV5

LAN-CAN-05

- DATA LINE
- L : LHD MODELS
- R : RHD MODELS
- \*1 13 : L
- 10 : R
- \*2 4 : L
- 3 : R



1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20							

(M75) : L  
BR

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(M75) : R  
BR

REFER TO THE FOLLOWING.  
(M118), (E122) -ELECTRICAL  
UNITS

## LAN-CAN-06

: DATA LINE

: LHD MODELS







: RHD MODELS

\*1 14:

9:

\*2 5:

2:




## Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	




SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
		F.F.DATA	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-54, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-54, "CHECK SHEET"](#).

**NOTE:**

- If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

5. According to the check sheet results (example), start inspection. Refer to [LAN-55, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

# CAN SYSTEM (TYPE 3)

[CAN]

## CHECK SHEET

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

Symptoms:

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

## CHECK SHEET RESULTS (EXAMPLE)

## NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.


## Case 1

Check harness between ESP/TCS/ABS control unit and 4WD control unit. Refer to [LAN-61, "Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—

PKIA9615E

//// : Malfunctioning part



PKIA9636E

# CAN SYSTEM (TYPE 3)

[CAN]


## Case 2

Check ECM circuit. Refer to [LAN-62, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—

PKIA9616E

//// : Malfunctioning part



PKIA9637E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 3

Check ESP/TCS/ABS control unit circuit. Refer to [LAN-63, "ESP/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN ✓	—	—	UNKWN
ABS	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN ✓	—	—	—

PKIA9617E



PKIA9638E

LAN


## Case 4

Check steering angle sensor circuit. Refer to [LAN-63, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

PKIA9619E

//// : Malfunctioning part



PKIA9639E

# CAN SYSTEM (TYPE 3)

[CAN]


## Case 5

Check 4WD control unit circuit. Refer to [LAN-64, "4WD Control Unit Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	UNKWN
ALL MODE AWD/4WD	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—

PKIA9618E



LAN

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 6

Check combination meter circuit. Refer to [LAN-64, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

PKIA9620E



PKIA9641E

**Case 7**

Check CAN communication circuit. Refer to [LAN-65. "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	—	—	UN <del>KN</del> ✓WN
ABS	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN
ALL MODE AWD/4WD	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	—	—

PKIA9621E

**Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection**

EKS00FV7

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E116
  - Harness connector M75

**OK or NG**

OK >> GO TO 2.

NG >> Repair terminal or connector.

**2. CHECK HARNESS FOR OPEN CIRCUIT**


1. Disconnect ESP/TCS/ABS control unit connector and harness connector E116.
2. Check the following.
  - LHD models
  - Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 14 (W), 5 (R).

**61 (W) – 14 (W)**

**: Continuity should exist.**

**63 (R) – 5 (R)**

**: Continuity should exist.**




- RHD models
- Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 9 (W), 2 (R).

**61 (W) – 9 (W)**

**: Continuity should exist.**

**63 (R) – 2 (R)**

**: Continuity should exist.**

**OK or NG**

OK >> GO TO 3.


NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector M75 terminals 14 (W), 5 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**14 (W) – 8 (W) : Continuity should exist.**


**5 (R) – 16 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector M75 terminals 9 (W), 2 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**9 (W) – 8 (W) : Continuity should exist.**

**2 (R) – 16 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-53, "Work Flow"](#).
- NG >> Repair harness.

## ECM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector M75
  - Harness connector E116

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Approx. 108 – 132Ω**

### OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and ESP/TCS/ABS control unit.



EKS00FV9

## ESP/TCS/ABS Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ESP/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector.
2. Check resistance between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace ESP/TCS/ABS control unit.  
 NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



EKS00FVE

## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M81 terminals 4 (W) and 5 (R).

**4 (W) – 5 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and 4WD control unit.



## 4WD Control Unit Circuit Inspection

EKS00FVA

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of 4WD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check resistance between 4WD control unit harness connector M107 terminals 8 (W) and 16 (R).

**8 (W) – 16 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace 4WD control unit.  
 NG >> Repair harness between 4WD control unit and steering angle sensor.



## Combination Meter Circuit Inspection

EKS00FVB

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and 4WD control unit.



EKS00FVC

## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, connector side and harness side).
  - ECM
  - ESP/TCS/ABS control unit
  - Steering angle sensor
  - 4WD control unit
  - Combination meter
  - Between ECM and combination meter

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector M75.
2. Check continuity between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector M75.



PKIA9592E

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector M118 terminals 94 (G/R), 86 (GY/R) and ground.


**94 (G/R) – Ground : Continuity should not exist.**

**86 (GY/R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector M75.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ESP/TCS/ABS control unit connector.
2. Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and ground.


**61 (W) – Ground : Continuity should not exist.**

**63 (R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect steering angle sensor connector, 4WD control unit connector and combination meter connector.
2. Check continuity between combination meter harness connector M44 terminals 22 (W) and 23 (R).


**22 (W) – 23 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between combination meter harness connector M44 terminals 22 (W), 23 (R) and ground.

**22 (W) – Ground : Continuity should not exist.**


**23 (R) – Ground : Continuity should not exist.**

OK or NO

OK >> GO TO 8.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 8. CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

Check components inspection. Refer to [LAN-67, "CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-53, "Work Flow"](#).


NG >> Replace ECM and/or combination meter.

### Component Inspection

#### CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 22 and 23.

Unit	Terminal	Resistance (Ω) (Approx.)
ECM	94 – 86	108 – 132
Combination meter	22 – 23	



## CAN SYSTEM (TYPE 4)

PFP:23710


## System Description

EKS00FVF

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## Component Parts and Harness Connector Location

EKS00FVG




Wiring Diagram — CAN —

EKS00FVH

LAN-CAN-07

- DATA LINE
- L : LHD MODELS
- R : RHD MODELS
- \*1 13 : L
- 10 : R
- \*2 4 : L
- 3 : R



1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20							


(M75) : L  
BR


1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					









(M75) : R  
BR

REFER TO THE FOLLOWING.  
(M118), (E122) -ELECTRICAL  
UNITS

## LAN-CAN-08

 : DATA LINE

 : LHD MODELS


 : RHD MODELS
\*1 14: 
9: 
\*2 5: 
2: 


## Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	




SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
		F.F.DATA	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-72, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-72, "CHECK SHEET"](#).

**NOTE:**

- If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

5. According to the check sheet results (example), start inspection. Refer to [LAN-73, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

# CAN SYSTEM (TYPE 4)

[CAN]

## CHECK SHEET

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

Symptoms:

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR



## CHECK SHEET RESULTS (EXAMPLE)

## NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

## Case 1

Check harness between ESP/TCS/ABS control unit and 4WD control unit. Refer to [LAN-79, "Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—

PKIA9615E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-80, "ECM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—

PKIA9616E



PKIA9637E


Case 3

Check ESP/TCS/ABS control unit circuit. Refer to LAN-81, "ESP/TCS/ABS Control Unit Circuit Inspection" .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

PKIA9617E

////// : Malfunctioning part



PKIA9638E

# CAN SYSTEM (TYPE 4)

[CAN]


## Case 4

Check steering angle sensor circuit. Refer to [LAN-81, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

PKIA9619E

//// : Malfunctioning part




PKIA9639E

Case 5

Check 4WD control unit circuit. Refer to [LAN-82, "4WD Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	UNKWN
ALL MODE AWD/4WD	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—

PKIA9618E



# CAN SYSTEM (TYPE 4)

[CAN]


## Case 6

Check combination meter circuit. Refer to [LAN-82, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	UNKWN	—	—	—

PKIA9620E

//// : Malfunctioning part



PKIA9641E

**Case 7**

Check CAN communication circuit. Refer to [LAN-83, "CAN Communication Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR						
	Initial diagnosis	Transmit diagnosis	Receive diagnosis				
			ECM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	—	—	UN <del>KN</del> ✓WN
ABS	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN
ALL MODE AWD/4WD	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	—	—

PKIA9621E

## Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection

EKS00FVJ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E116
  - Harness connector M75

#### OK or NG


- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector and harness connector E116.
2. Check the following.
  - LHD models
  - Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 14 (W), 5 (R).

**61 (W) – 14 (W) : Continuity should exist.**


**63 (R) – 5 (R) : Continuity should exist.**



- RHD models
- Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 9 (W), 2 (R).

**61 (W) – 9 (W) : Continuity should exist.**

**63 (R) – 2 (R) : Continuity should exist.**



#### OK or NG


- OK >> GO TO 3.  
 NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector M75 terminals 14 (W), 5 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**14 (W) – 8 (W) : Continuity should exist.**


**5 (R) – 16 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector M75 terminals 9 (W), 2 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**9 (W) – 8 (W) : Continuity should exist.**

**2 (R) – 16 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-71, "Work Flow"](#).
- NG >> Repair harness.

## ECM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector M75
  - Harness connector E116

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M118 terminals 95 (G/R) and 87 (GY/R).

**95 (G/R) – 87 (GY/R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and ESP/TCS/ABS control unit.



EKS00FVL

## ESP/TCS/ABS Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ESP/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector.
2. Check resistance between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Approx. 54 – 66Ω**

OK or NG

- OK >> Replace ESP/TCS/ABS control unit.  
 NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



EKS00FVM

## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M81 terminals 4 (W) and 5 (R).

**4 (W) – 5 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and 4WD control unit.



## 4WD Control Unit Circuit Inspection

EKS00FVN

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of 4WD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check resistance between 4WD control unit harness connector M107 terminals 8 (W) and 16 (R).

**8 (W) – 16 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace 4WD control unit.  
 NG >> Repair harness between 4WD control unit and steering angle sensor.



## Combination Meter Circuit Inspection

EKS00FVO

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and 4WD control unit.



EKS00FVP

## CAN Communication Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, connector side and harness side).
  - ECM
  - ESP/TCS/ABS control unit
  - Steering angle sensor
  - 4WD control unit
  - Combination meter
  - Between ECM and combination meter

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector M75.
2. Check continuity between ECM harness connector M118 terminals 95 (G/R) and 87 (GY/R).

**95 (G/R) – 87 (GY/R) : Continuity should not exist.**

OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector M75.



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector M118 terminals 95 (G/R), 87 (GY/R) and ground.


**95 (G/R) – Ground : Continuity should not exist.**

**87 (GY/R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector M75.



### 4. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect ESP/TCS/ABS control unit connector.
2. Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and ground.


**61 (W) – Ground : Continuity should not exist.**

**63 (R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect steering angle sensor connector, 4WD control unit connector and combination meter connector.
2. Check continuity between combination meter harness connector M44 terminals 22 (W) and 23 (R).


**22 (W) – 23 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between combination meter harness connector M44 terminals 22 (W), 23 (R) and ground.

**22 (W) – Ground : Continuity should not exist.**


**23 (R) – Ground : Continuity should not exist.**

OK or NO

OK >> GO TO 8.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 8. CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

Check components inspection. Refer to [LAN-85, "CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-71, "Work Flow"](#).


NG >> Replace ECM and/or combination meter.

### Component Inspection

#### CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 95 and 87.
- Check resistance between combination meter terminals 22 and 23.

Unit	Terminal	Resistance (Ω) (Approx.)
ECM	95 – 87	108 – 132
Combination meter	22 – 23	




**CAN SYSTEM (TYPE 5)****System Description**

EKS00FWG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

**Component Parts and Harness Connector Location**

EKS00FWH



# CAN SYSTEM (TYPE 5)


[CAN]


## Wiring Diagram — CAN —

EKS00FWI

LAN-CAN-09

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



1	2	3	4	5	6			7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22	23	24

1	2	3	4	5		6	7	8	9	
10	11	12	13	14	15	16	17	18	19	20

(M75)  
BR

1	2	3	4	5
6	7	8	9	

(F36) GY

REFER TO THE FOLLOWING.

(M118), (E122), (F46)  
-ELECTRICAL UNITS

TKWB0114E

## LAN-CAN-10

: DATA LINE

: LHD MODELS







: RHD MODELS

\*1 14:

9:

\*2 5:

2:






## Work Flow

1. Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	




SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		0	
		F.F.DATA	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PKIA8260E

2. Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "ABS" and "ALL MODE AWD/4WD" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE			
WORK SUPPORT			
SELF-DIAG RESULTS			
DATA MONITOR			
DATA MONITOR (SPEC)			
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
			Scroll Down
BACK	LIGHT	COPY	



CAN DIAG SUPPORT MNTR			
ENGINE			
		PRSENT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8343E

3. Attach the printed sheet of "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-90, "CHECK SHEET"](#).
4. Based on the "CAN DIAG SUPPORT MNTR" results, put marks "v" onto the items with "NG" or "UNKWN" in the check sheet table. Refer to [LAN-90, "CHECK SHEET"](#).

**NOTE:**

- If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.  
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

5. According to the check sheet results (example), start inspection. Refer to [LAN-91, "CHECK SHEET RESULTS \(EXAMPLE\)"](#).

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET

### NOTE:

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

Symptoms:

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
ALL MODE AWD/4WD  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ALL MODE AWD/4WD  
CAN DIAG SUPPORT  
MNTR

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and ESP/TCS/ABS control unit. Refer to [LAN-99, "Between TCM and ESP/TCS/ABS Control Unit Circuit Inspection"](#).

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—

PKIA9623E




PKIA9642E

Case 2

Check harness between ESP/TCS/ABS control unit and 4WD control unit. Refer to [LAN-101, "Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	—

PKIA9624E




Case 3

Check ECM circuit. Refer to [LAN-103, "ECM Circuit Inspection"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

PKIA9625E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-104, "TCM Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN ✓	UNKWN	—	—	UNKWN
A/T	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

PKIA9626E




PKIA9645E

Case 5

Check ESP/TCS/ABS control unit circuit. Refer to [LAN-104, "ESP/TCS/ABS Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN ✓	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN
ABS	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—

PKIA9627E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 6

Check steering angle sensor circuit. Refer to [LAN-105, "Steering Angle Sensor Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

PKIA9629E



PKIA9647E




Case 7

Check 4WD control unit circuit. Refer to [LAN-105, "4WD Control Unit Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

PKIA9628E



A

B

C

D

E

F

G

H

I

J

L


M

**Case 8**

Check combination meter circuit. Refer to [LAN-106, "Combination Meter Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UNKWN	—	UNKWN	UNKWN	—	—	UNKWN ✓
A/T	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN ✓
ABS	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
ALL MODE AWD/4WD	NG	UNKWN	UNKWN	—	UNKWN	—	—	—

PKIA9630E



PKIA9649E

**Case 9**

Check CAN communication circuit. Refer to [LAN-107. "CAN Communication Circuit Inspection"](#) .

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR							
	Initial diagnosis	Transmit diagnosis	Receive diagnosis					
			ECM	TCM	VDC/TCS /ABS	STRG	AWD/4WD	METER/M&A
ENGINE	NG	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	—	UN <del>KN</del> ✓WN
A/T	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	—	—	UN <del>KN</del> ✓WN
ABS	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN
ALL MODE AWD/4WD	NG	UN <del>KN</del> ✓WN	UN <del>KN</del> ✓WN	—	UN <del>KN</del> ✓WN	—	—	—

PKIA9631E

**Between TCM and ESP/TCS/ABS Control Unit Circuit Inspection**

EKS00FWK

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - LHD models
    - Harness connector F41
    - Harness connector M61
    - Harness connector M75
    - Harness connector E116
  - RHD models
    - Harness connector F36
    - Harness connector E60

**OK or NG**

OK >> GO TO 2.

NG >> Repair terminal or connector.

LAN


## 2. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models

1. Disconnect TCM connector and harness connector F41.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and harness connector F41 terminals 21 (G/R), 8 (GY/R).

**5 (G/R) – 21 (G/R) : Continuity should exist.**


**6 (GY/R) – 8 (GY/R) : Continuity should exist.**



3. Disconnect harness connector M75.
4. Check continuity between harness connector M61 terminals 21 (L/R), 8 (B/W) and harness connector M75 terminals 13 (L/R), 4 (B/W).

**21 (L/R) – 13 (L/R) : Continuity should exist.**

**8 (B/W) – 4 (B/W) : Continuity should exist.**




### RHD models

1. Disconnect TCM connector and harness connector F36.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and harness connector F36 terminals 4 (G/R), 5 (GY/R).

**5 (G/R) – 4 (G/R) : Continuity should exist.**

**6 (GY/R) – 5 (GY/R) : Continuity should exist.**



### OK or NG


- OK >> GO TO 3.  
 NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector E116 terminals 13 (W), 4 (R) and ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R).

**13 (W) – 61 (W) : Continuity should exist.**


**4 (R) – 63 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector E60 terminals 4 (W), 5 (R) and ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R).

**4 (W) – 61 (W) : Continuity should exist.**

**5 (R) – 63 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-89, "Work Flow"](#).
- NG >> Repair harness.

### Between ESP/TCS/ABS Control Unit and 4WD Control Unit Circuit Inspection

EKS00FWL

#### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector E116
  - Harness connector M75

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector and harness connector E116.
2. Check the following.

- LHD models
- Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 14 (W), 5 (R).

**61 (W) – 14 (W) : Continuity should exist.**


**63 (R) – 5 (R) : Continuity should exist.**



- RHD models
- Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and harness connector E116 terminals 9 (W), 2 (R).

**61 (W) – 9 (W) : Continuity should exist.**

**63 (R) – 2 (R) : Continuity should exist.**



OK or NG


- OK >> GO TO 3.  
NG >> Repair harness.

### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check the following.
  - LHD models
  - Check continuity between harness connector M75 terminals 14 (W), 5 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**14 (W) – 8 (W) : Continuity should exist.**


**5 (R) – 16 (R) : Continuity should exist.**



- RHD models
- Check continuity between harness connector M75 terminals 9 (W), 2 (R) and 4WD control unit harness connector M107 terminals 8 (W), 16 (R).

**9 (W) – 8 (W) : Continuity should exist.**

**2 (R) – 16 (R) : Continuity should exist.**



#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-89, "Work Flow"](#).
- NG >> Repair harness.

## ECM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - ECM connector
  - Harness connector M61
  - Harness connector F41

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Approx. 108 – 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between ECM and TCM.



EKS00FWN

## TCM Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Approx. 54 – 66Ω**

OK or NG


OK >> Replace TCM.

NG >> ● LHD models

– Repair harness between TCM and harness connector F41.

● RHD models

– Repair harness between TCM and harness connector F36.



EKS00FWO

## ESP/TCS/ABS Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ESP/TCS/ABS control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.




## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ESP/TCS/ABS control unit connector.
2. Check resistance between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace ESP/TCS/ABS control unit.  
 NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



EKS00FWT

## Steering Angle Sensor Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M81 terminals 4 (W) and 5 (R).

**4 (W) – 5 (R) : Approx. 54 – 66Ω**

### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor and 4WD control unit.



EKS00FWP

## 4WD Control Unit Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of 4WD control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect 4WD control unit connector.
2. Check resistance between 4WD control unit harness connector M107 terminals 8 (W) and 16 (R).

**8 (W) – 16 (R) : Approx. 54 – 66Ω**

OK or NG

- OK >> Replace 4WD control unit.  
 NG >> Repair harness between 4WD control unit and steering angle sensor.



EKS00FWQ

## Combination Meter Circuit Inspection

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M44 terminals 22 (W) and 23 (R).

**22 (W) – 23 (R) : Approx. 108 – 132Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter and 4WD control unit.



## CAN Communication Circuit Inspection

EKS00FWR

## 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, sensor side, meter side, connector side and harness side).
  - ECM
  - TCM
  - ESP/TCS/ABS control unit
  - Steering angle sensor
  - 4WD control unit
  - Combination meter
  - Between ECM and combination meter

## OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ECM connector and harness connector M61.
2. Check continuity between ECM harness connector M118 terminals 94 (G/R) and 86 (GY/R).

**94 (G/R) – 86 (GY/R) : Continuity should not exist.**

## OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector M61.



## 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector M118 terminals 94 (G/R), 86 (GY/R) and ground.

**94 (G/R) – Ground : Continuity should not exist.**

**86 (GY/R) – Ground : Continuity should not exist.**

## OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness between ECM and harness connector M61.




## 4. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models


1. Disconnect TCM connector.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Continuity should not exist.**



3. Disconnect harness connector M75.
4. Check continuity between harness connector M61 terminals 21 (L/R) and 8 (B/W).


**21 (L/R) – 8 (B/W) : Continuity should not exist.**



### RHD models

1. Disconnect TCM connector and harness connector F36.
2. Check continuity between TCM harness connector F46 terminals 5 (G/R) and 6 (GY/R).

**5 (G/R) – 6 (GY/R) : Continuity should not exist.**



### OK or NG

OK >> GO TO 5.

NG >> ● LHD models

Check the following harness. If any harness is damaged, repair the harness.

- Harness between TCM and harness connector F41
- Harness between harness connector M61 and harness connector M75

● RHD models

- Repair harness between TCM and harness connector F36.


## 5. CHECK HARNESS FOR OPEN CIRCUIT

### LHD models

1. Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and ground.

**5 (G/R) – Ground : Continuity should not exist.**


**6 (GY/R) – Ground : Continuity should not exist.**



2. Check continuity between harness connector M61 terminals 21 (L/R), 8 (B/W) and ground.

**21 (L/R) – Ground : Continuity should not exist.**

**8 (B/W) – Ground : Continuity should not exist.**




### RHD models

- Check continuity between TCM harness connector F46 terminals 5 (G/R), 6 (GY/R) and ground.

**5 (G/R) – Ground : Continuity should not exist.**

**6 (GY/R) – Ground : Continuity should not exist.**



### OK or NG

OK >> GO TO 6.

NG >> • LHD models

Check the following harness. If any harness is damaged, repair the harness.


- Harness between TCM and harness connector F41
- Harness between harness connector M61 and harness connector M75
- RHD models
- Repair harness between TCM and harness connector F36.

## 6. CHECK HARNESS FOR SHORT CIRCUIT

LHD models

1. Disconnect ESP/TCS/ABS control unit connector.
2. Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).


**61 (W) – 63 (R) : Continuity should not exist.**



RHD models

1. Disconnect ESP/TCS/ABS control unit connector and harness connector E116.
2. Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W) and 63 (R).

**61 (W) – 63 (R) : Continuity should not exist.**



OK or NG

OK >> GO TO 7.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.

## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ESP/TCS/ABS control unit harness connector E122 terminals 61 (W), 63 (R) and ground.


**61 (W) – Ground : Continuity should not exist.**

**63 (R) – Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Repair harness between ESP/TCS/ABS control unit and harness connector E116.



## 8. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect steering angle sensor, 4WD control unit connector and combination meter connector.
2. Check continuity between combination meter harness connector M44 terminals 22 (W) and 23 (R).


**22 (W) – 23 (R) : Continuity should not exist.**

OK or NG

OK >> GO TO 9.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 9. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between combination meter harness connector M44 terminals 22 (W), 23 (R) and ground.

**22 (W) – Ground : Continuity should not exist.**


**23 (R) – Ground : Continuity should not exist.**

OK or NO

OK >> GO TO 10.

NG >> Check the following harness. If any harness is damaged, repair the harness.

- Harness between combination meter and 4WD control unit
- Harness between combination meter and steering angle sensor
- Harness between combination meter and harness connector M75



## 10. CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

Check components inspection. Refer to [LAN-111, "CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT"](#).

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-89, "Work Flow"](#).

NG >> Replace ECM and/or combination meter.

### Component Inspection

#### CHECK ECM AND COMBINATION METER INTERNAL CIRCUIT

- Remove ECM and combination meter from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between combination meter terminals 22 and 23.

Unit	Terminal	Resistance (Ω) (Approx.)
ECM	94 – 86	108 – 132
Combination meter	22 – 23	

